


DRESSER

MAKE YOUR HOUSE YOUR HOME






Read all assembly and care instructions carefully before using this product. Save these instructions for future reference.

- Select a smooth, level surface to place the dresser.
- Assemble components on a soft, clean surface to avoid scratching and/or damaging the finish.
- Ensure all parts are accounted for before disposing of packaging.
- Using incompatible hardware might cause damages to product.
- This package contains small parts. Keep away from children prior and during assembly. Adult assembly is required.



ASSEMBLY

PARTS DETAILS

ID	DESCRIPTION	QTY
A	TOP BOARD	1
B	SIDE BOARD RIGHT	1
C	SIDE BOARD LEFT	1
D	MIDDLE BOARD	1
E	BOTTOM BOARD	1
F	BACK BOARD 1	1
G	BACK BOARD 2	1
H	MIDDLE BAR	2
J1	LEFT LEG	2
J2	RIGHT LEG	2
K	DRAWER FRONT	6
L	SIDE DRAWER RIGHT	6
M	SIDE DRAWER LEFT	6
N	BACK DRAWER	6
O	BOTTOM DRAWER	6
P	HANDLE	6



HARDWARE LIST

ID	DESCRIPTION	QTY
1	ALLEN KEY 	2
2	BOLTS M8X80 	4
3	BOLTS M6 X30 	12
4	CAMLOCK PIN 	48
5	CAMLOCK 	48
6	SCREWS M3. 5X12 	12
7	SCREWS M4X25 	4

IMPORTANT INFORMATION

Under normal use, Dresser will last for years. It is, however, important to follow basic care tips to prolong the life of your Dresser.

USE & CARE

- Clean the product with mild cleanser using soft dampened cloth.
- Do not use harsh or abrasive cleansers.
- Alter the finish might damage the integrity of the product.
- Avoid dragging sharp or rough objects across the surface.
- Avoid direct sunlight exposure.
- Do not place near heating units or vents.
- Promptly wipe up any spills or any other moisture.

TROUBLESHOOTING

If the Dresser seems unstable, make sure it is on a level surface and the feet are correctly distributed as shown in the assembly instructions. Also make sure that all components are assembled correctly and the hardware is securely tightened.

Any modification or failure to follow the recommended care will void the product warranty.

WARRANTY INFORMATION

Thank you for choosing us. We stand behind our brand and the quality of the items we sell. We is not responsible for normal wear and tear, for products used commercially or for failures caused by accidents, abuse, alteration, modification, misuse or improper care. There are no other express warranties beyond the terms of this limited warranty. In no event shall any implied warranties, including merchantability and fitness for a particular purpose, extend beyond the duration of the express warranty contained herein. In no event shall we be liable for incidental or consequential damages. For warranty duration, please refer to our website. Replacement parts or products will be sent at our discretion if the defect is the result of any fault on our side. Proof of purchase, with the date of purchase as well as photos of the defective merchandise, must be provided. Photos are used to determine the cause of defects and for future quality control. Please contact Customer Service directly; or if you have any questions, comments or concerns by emailing us.





WARNING!

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product, external influence, and force majeure.

SOFT CLOSING DRAWERS


ADJUSTMENT INSTRUCTIONS

FIXED A CROOKED DRAWER





Adjust levelers on either side of drawer as needed to straighten drawer.

11




Adjust levelers legs as needed..





1



Allen key
2x

2



M8 x 80
4x

3




M6 x 30
12x

4



Camlock pin
48x

5




Camlock
48x

6




Screws
M3.5 x 12
12x

7




Screws
M4 x 25
4x




2D


Align brackets on unit with brackets on wall.




2E






Pull strap down until it snap-locks.

2A

Attach pair of brackets to top corners of the back of the unit. Note there are no existing pilot holes on the product.




2B

Mark on wall where second pair of brackets should be placed.



2C

Drill holes in wall using 8mm / 5/16" drill bit.

1






2





Fully tighten bolts

3



4






ANTI-TIP RESTRAINT INSTALLATION

WARNING!

Children have died from furniture tipover.

To reduce the risk of furniture tipover:


- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lower drawers.




TIME




#OF PEOPLE






DIFFICULTY



REQUIRED TOOL
8MM / 5/16" DRILL BIT



REQUIRED TOOL

PARTS INVENTORY		
ID	DESCRIPTION	QTY
A	BRACKET 	4
B	M4 x 20MM SCREW 	4
C	M8 x 51MM PLUG 	4
D	M6 x 70MM SCREW 	4
E	STRAP 	2




Hardware (C/D) to attach brackets to wall is designed for drywall. To attach this unit to another type of wall, consult with your local hardware store.


10

INSTALL DRAWER




Step 1





Step 2





5



6



7



8

