

FAQ

Q1: No remote or power adapter in the box.

A: Please check the package again (side pocket or seat bottom), and contact us if still fail to find.

Q2: Where are the anti-tipping brackets ⑦?

A: The brackets are packed on the bottom of the metal frame. Check the attachment.



Q3: The backrest or armrests are shaky after installation.

A: Check whether all the metal inserts slide successfully. If not, please reinstall.

Q4: The cords don't match the adapter.

A: There are 2 cords fastened on the back of the metal frame (see attachment). Round-headed cord is for the remote and the other for power adapter.



Q5: The chair can not lift or recline.

A: **Step 1:** Check whether the remote is powered. (The indicator light for adapter will be on when powered.)
Step 2: Please contact us if the chair still can not lift or recline after above attempt. Our customer service team will solve the problem for you.




Q6: How to clean the liquid stains on the sofa?

A: Spot-cleaning by the fabric cleaner gently.

Q7: How to detach/remove the backrest from the seat base?

A: Please pull the brackets as seen in the pic.



LIFT RECLINER



INSTALLATION INSTRUCTIONS


PACKAGE PARTS



INSTALLATION



Step 1: Install the anti-tipping brackets ⑦ to seat base ②.




Step 2: Align the armrests ④ to seat base ② as shown above. Then insert firmly. **Step 3:** Place the backrest ① on seat base ② and align the metal inserts as above. Then insert firmly.



Step 4: Install the backrest firmly.

Step 5: Install the wing backs ③ on both sides.

(Please check whether the metal inserts slide successfully before next step.)



Step 6: Connect relative cords for the remote and power adapter.

(There are 2 cords/jacks fastened at the back of the seat base. A is for the remote and B is for power adapter.)

MAINTENANCE



- To avoid being damaged, please carry and move the sofa carefully.
- Wipe the dirt or dust away with sponge or clean cloth gently.
- Keep away from direct-sunlight area or air-conditioner.

WARNING



Keep kids away from the chair when in use.



No sitting on the back or extended footrest.



No sitting on the arm.



No jumping. No standing up when the chair is reclined.