


Wardrobe



IMPORTANT INFORMATION!

- please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.

AVOID SCRATCHES!

- In order to avoid scratching this furniture should be assembled on a soft layer-could be a rug.

IMPROVE EFFICIENCY!

- Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.

IMPORTANT!


- It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months -in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag.
for glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.




- Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.

ANTI-TOPPLE WARNING!

Overtumed furniture can cause serious or fatal crush injuries. to prevent tipping over, be sure to use the wall attachment, if not included with this product. please purchase the wall attachment that fit your wall. if unsure, seek professional advice. please read and follow each step of the instructions carefully.



Please prepare the following tools



When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 62



Ø6 x 34mm

B x 62



Ø15 x 10mm

C x 24




Ø8*30mm

D x 98



Ø3.5*14mm

E x 8




350mm

F x 8



Ø4*12mm

G x 6



Ø4*22mm

H x 4



114mm

J x 3




146mm

K x 3




Ø35mm

L x 6



Ø35mm


M x 19




N x 2



P x 2



Q x 16




Ø3.5*35mm

R x 1




772mm



Slides Must be Separated Before Assembly.
After Separated, Set Aside Until Needed for Assembly.

Las diapositivas deben separarse antes del montaje.
Después de la separación, déjelo a un lado hasta que sea necesario.

Les glissières doivent être séparées avant l'assemblage.
Après la séparation, mettez de côté jusqu'au moment de l'assemblage.






1

A x 8
Ø6 x 34mm




D x 16
Ø3.5*14mm

E x 8
350mm



2

A x 4
Ø6 x 34mm





3

B x 4



Ø15 x 10mm






4


B x 8



Ø15 x 10mm



5






6

A x 12



Ø6 x 34mm



7

B x 6







Ø15 x 10mm

C x 6



Ø8*30mm



8

A x 6







Ø6 x 34mm

D x 2



Ø3.5*14mm

N x 1






9

A x 2



Ø6 x 34mm



10

B x 2






Ø15 x 10mm

C x 2



Ø8*30mm



11

B x 4







Ø15 x 10mm

C x 4



Ø8*30mm



12

A x 10








Ø6 x 34mm

D x 2



Ø3.5*14mm

N x 1



13

B x 12





C x 8



Ø15 x 10mm



Ø8*30mm



14

B x 6




C x 6





Ø15 x 10mm



Ø8*30mm



15





1. Firstly, embed the backboard to the slot.
2. Stand the entire closet up when the backboard is spaced of 4in/10cm inside the bottom slot.
3. Finally, fully embed the backboard in the bottom slot.

16

R x 1



772mm



17



A x 20



Ø6 x 34mm



x2




18



B x 18





Ø15 x 10mm



x2



19



x2

20

B x 2






Ø15 x 10mm


Q x 16



Ø3.5*35mm







x2




21



D x 16	E x 8	F x 8	H x 4
 Ø3.5*14mm	 E1 E2 350mm	 Ø4*12mm	 114mm



x2




22





23

D x 18	K x 3	L x 6
		
Ø3.5*14mm	Ø35mm	Ø35mm



24

D x 36	G x 6	J x 3
		
Ø3.5*14mm	Ø4*22mm	146mm




25

D x 8





Ø3.5*14mm

M x 19





26



P x 2





Up & Down Adjustment



Left & Right Adjustment



Forward & Back Adjustment



WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly.the warranty will start from the date of purchase which must be verified by proof of purchase.
- The product must be used in accordance with the instructions provided.for health reasons.
- For other reasons,if the furniture needs to be returned,it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty.attention please.
- Does not include damage during installation,but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and /or loss of parts during the installation of furniture.
- After using,the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All bought in The us and Covers The Following areas

- Sheet parts:1 month from the date of purchase.
- Electrical parts:1 month from the date of purchase.