






TODDLER SWING - BSW02
FOR CHILDREN 6 - 36 MONTHS

SAFETY GUIDELINES

Warnings
Only for domestic use. This product has not been designed for commercial use in play centers, nurseries etc.
Suitable for indoor and outdoor use.
Not for children with a body weight over 20kg. Only one child per seat at any one time.
This equipment must be assembled and checked by an adult. Two adults may be required to assemble this product. Adult supervision is required at all times.
Always fasten the harness when the child is seated.
The minimum clearance between the swing seat and ground level should be 200mm.
Check all nuts, bolts and fittings for tightness and tighten if required.
Check all coverings for bolts and sharp edges and replace when required.
Check swing seats, chain, ropes and other means of attachments if relevant to your product for evidence of deterioration. Replace when required in accordance with the manufacturers instructions if necessary.
Place the product on level surface at least 2 metres from any structure or obstruction such as a fence, garage, house, wall, overhanging branches, laundry line or electrical wires.
DO NOT install the product over concrete, asphalt or any hard surface.
DO NOT orientate the product directly towards the sun.
Leave all fittings finger tight until assembly is complete, for ease of construction. Then tighten firmly.
Children should not wear cycle helmets whilst on this equipment.
Do not allow children to stand on any swing seats, glider seats or slide chutes relevant to your product.
Do not allow the children to jump or climb off any moving equipment.
Do not twist swing ropes or wrap them over the top bar.
Do not allow loose, hooded or baggy clothes to be worn as children can get trapped and may be unable to free themselves.
Do not allow children to climb on parts of this equipment not intended for this purpose.
Do not allow children to wander into the play area whilst the equipment is in use.
Gliders and swings must not exceed an angle of 60 degrees from the ground.
Regularly check the item for wear and damage, removing the item from use when necessary until replacement parts are fitted.
Failure to assemble and maintain this item as per instruction may cause injury to the user.
Please keep the instructions in a safe place for future reference.
Please contact our customer services department if you have any problems.
Do not modify this item.

SWING PARTS LIST



IMPORTANT: Make sure you read the safety notice on the front page and always supervise children while they are playing on the equipment. Once assembly is completed carefully check equipment. In the unlikely event that you do find any problems, please contact us. Do not allow children to use this product until the problem has been corrected.

STEP 1 Seat Assembly





Step A:
Carefully fold over the seat armrest followed by the base as shown in the diagram.



Step B:
Position the back so that it is at a 90 degree angle to the base, pushing down on it until it clicks into place.

Step C:
Once the seat has been aligned, push the two orange pins firmly into the sides of the seat until they fully fit into the backrest. Please note that if the pins are forced into the seat when it has not been aligned, it will cause the pins to break.


STEP 2
Frame & Swing Assembly



STEP 3
Frame Assembly



STEP 4 Seat Belt Assembly



Take Care When Seating Your Child!
The child must be secured to the seat immediately to avoid any injury.

