


USE AND CARE GUIDE

4 SQUARE FLOOR LAMP



THANK YOU

We appreciate the trust and confidence you have placed in us through the purchase of this lamp. We strive to continually create quality products designed to enhance your home.

Thank you for choosing us!

Table of Contents

Safety Information	2
Warranty	2
Pre-Installation	3
Planning Installation	3
Package Contents	3
Assembly	4, 5, 6
Care and Cleaning	7
Troubleshooting	7

Safety Information

☐ Consult a qualified electrician with any electrical questions you may have.



IMPORTANT: Inspect the wire insulation for any cuts, abrasions, or exposed copper that may have occurred during shipping. If there is a defect in the wire, do not continue the assembly process. Please call our Customer Service Team.

Warranty

1-YEAR LIMITED WARRANTY

WHAT IS COVERED

The manufacturer warrants this lamp to be free from defects in the materials and workmanship for a period of one (1) year from date of purchase. This warranty applies only to the original consumer purchaser and only to products used in normal use. If this product is found to be defective, the manufacturer's only obligation, and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alterations, neglect or mishandling. This warranty shall not apply to any product that is found to have been improperly installed, assembled, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, faulty installation, or any other failure not relating to faulty material or workmanship.

WHAT IS NOT COVERED

This warranty shall not apply to the finish on any portion of the product due to weathering, as this is considered normal wear. The manufacturer does not warrant and specifically disclaims any warranty, whether expressed or implied, other than the warranty contained herein. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including but not limited to, any labor or expense costs involved in the replacement or repair of the product.


Pre-Installation

PLANNING INSTALLATION

Read all instructions before assembly.


To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard. Inspect each part for defects that may have occurred during shipping.

Keep your receipt and these instructions for proof of purchase.



NOTE: This lamp requires the use of one 120V, 60Hz, 150-Watt max, medium-base type A bulb (not included). Do not exceed the recommended wattage.

PACKAGE CONTENTS



Part	Description	Quantity
A	Socket ring	1
B	Shade	1
C	Socket assembly	1
D	Inner pole	1
E	Pole	1


Part	Description	Quantity
F	Base	1
G	Metal washer	2
H	Nut	1
I	Wrench	1

Assembly instructions

1. Unpack the lamp & pole assemble

- Carefully organize and place all parts on a smooth, flat surface, line up all of the parts according to the assembly diagram.
- Screw the inner pole (D) to bottom of the socket assembly (C).
- Pull the excess power cord through the pole (E).
- Slide the pole (E) over the inner pole (D), make sure the pin on bottom of the socket assembly (C) is inserted into the pole (E).


NOTE: make sure the cord exits from back of the lamp as shown.



Assembly instructions (continued)

2. Assemble the base and shade


- Insert end of the inner pole (D) into the hole in the base (F), put the nut (H) into the wrench (I) (included), and then secure the pole (E) to the base (F) with the two metal washers (G) and nut (H) from bottom of the base (F).
- Remove the socket ring (A) from the socket by unscrewing the socket ring (A).
- Place the shade (B) over the socket and secure with the socket ring (A).



Assembly instructions (continued)

3. Install the bulb

- ❑ Prior to installing the bulb, inspect the socket for silica packet. If packet is present, then remove and throw away. Do not expose it to children or pets.
- ❑ Install one 120V, 60Hz, 150-Watt max, medium-base type A bulb (not included) into the socket of the light lamp.
- ❑ Plug cord into an outlet and turn on at the switch.



Important safety instructions

☐ This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

Care and Cleaning

☐ Clean the lamp with a soft, dry cloth. Do not use any cleaners with chemicals, solvents, or harsh abrasives.

Troubleshooting

Problem	Possible Cause	Solution
The bulb will not light.	<input type="checkbox"/> The bulb is burned out.	<input type="checkbox"/> Replace the light bulb.
	<input type="checkbox"/> The power is off.	<input type="checkbox"/> Ensure that the power supply is turned on.
	<input type="checkbox"/> Did not insert plug into power outlet.	<input type="checkbox"/> Ensure that the plug is fully and properly inserted into the power outlet.
	<input type="checkbox"/> The circuit breaker is off.	<input type="checkbox"/> Ensure that the circuit breaker is set in the on position.
The fuse blows or a circuit breaker trips when the light is turned on.	<input type="checkbox"/> There is an exposed wire. <input type="checkbox"/> There are too many items on one circuit.	<input type="checkbox"/> Discontinue use of the lamp. <input type="checkbox"/> Contact a qualified electrician or call the Customer Service Team. <input type="checkbox"/> Unplug other items on the circuit.