


Entertainment Center

IMPORTANT


Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.

Carefully and strictly follow these assembly instructions to ensure a completed product as designed.


Do not use power tools above 8 volts to assemble.



Part List



Hardware List




Tool(s) required for assembly: Phillips screwdriver, Level, Drill (8 volts or less), 3/8" Drill Bit

Assembly Instructions 2/5

IMPORTANT


- Use a soft cloth between these parts and the floor.
- Do not use power tools above 8 volts to assemble.
- Do not tighten all the bolts until each part is properly assembled.
- The unit must be level to work properly. Use the included adjustable levelers to level.
- Keep Hex Wrench in a safe place as the bolts may need to be tightened up in the future.



STEP 1

Place Base (B) upside down on a soft cloth.

Attach Feet (O) to Base (B).



STEP 2

Turn unit over to its' upright position.

Attach Side Panel (E) to unit with Flat Washers, Spring Washers and Head Cap Bolts. (See Figure 1)

Attach Middle Panels (G) and (H) to unit, then flip the locks. (See Figures 2 and 3)

Slide Back Panels (I) and (J) into position.




Figure 1




Figure 2




Figure 3

Assembly Instructions 3/5

STEP 3

Attach Magnets to Front Stretcher (C) with Wood Screws into pre-drilled holes.
(See Figure 4)






Figure 4



STEP 4



Attach Front Rail (C) and Back Rail (D) to unit, then flip the locks.

Attach Side Panel (F) to unit with Flat Washers, Spring Washers and Head Cap Bolts, then flip the locks.

Assembly Instructions 4/5

STEP 5

Attach Top (A) to unit with Flat Washers, Spring Washers and Head Cap Bolts, then flip the locks.



STEP 6

Insert Adjustable Pins into side panels and middle panels at desired level. (See Figure 5)

Place Shelves (K) and (L) into position.

Attach Doors (M) and (N) by sliding door lift hinges into side panel lift hinges. (See Figure 6)

Attach Knobs to Doors (M) and (N) with Machine Screws. (See Figure 7)

Level unit by adjusting the adjustable levelers on bottom of unit. (See Figure 8)




Figure 5




Figure 6




Figure 7




Figure 8

Assembly Instructions 5/5

IMPORTANT

- To help reduce the risk of the unit tipping over, the Tip-over Restraint must be installed following these instructions exactly.

STEP 7

Place unit at desired location.

Drill a 3/8" hole in wall in-line with pre-drilled hole at top of unit.

Move unit.

Insert Anchor into the wall hole and attach Bracket with Wall Screw.

Attach Bracket at pre-drilled hole at top of unit with Wood Screw.

Move unit back into place.

Slide Tip-over Restraint through Bracket on wall and Bracket on unit.
(See Figure 9)

Put tie end of Tip-over Restraint into lock end of Tip-over Restraint and pull until tight.







Figure 9




Hardware List



Anchor
1 pc. (+1 extra)



Bracket
2 pcs. (+1 extra)



Tip-over Restraint
1 pc. (+1 extra)



M3.5x40
Wall Screw
1 pc. (+1 extra)



M3.5x16
Wood Screw
1 pc. (+1 extra)

CARE INSTRUCTIONS

NEVER

allow liquids to remain on furniture.
Absorption causes parts to warp
and split and finishes to delaminate.

NEVER

use glass cleaners on
finished furniture. Ammonia
chemically attacks the finish.



Do not use power tools
above 8 volts to assemble.
**PREVENT
CRACKING**



Do not place
in direct sunlight.
**PREVENT
FADING**



Do not write
directly on surface.
**PREVENT
MARKING**



Do not place hot
objects on surface.
**PREVENT
FINISH DAMAGE**



Do not use rubber
based placemats.
**PREVENT
DISCOLORING**



Do not use commercial
waxes and polishes.
**PREVENT
YELLOWING**

CLEAN

with a soft cloth moistened
in lukewarm soap and water.
Buff with a dry clean cloth.



We will provide replacements free of charge for missing or damaged hardware or parts within 30 days of purchase. Digital images of the defective parts may be required. If the product was not purchased from an authorized retail affiliate, We are under no obligation to provide replacement parts. Parts are not available for fully assembled items nor are parts available for sale.