

WALL ART HANGING GUIDE

What we include for you:



Screws




Wall Anchors

1.




Mark where your screws will go; make sure the marks are leveled and spaced apart as needed. A beam level is nifty for this.

2.




Drill a 3/16" in diameter hole through wall.

3.



Tap the supplied wall anchor firmly into drilled holes.

4.



Carefully drill the screws into wall, leaving the screw heads protruding from the wall surface.

5.



Hang your art and enjoy!

Thank you for your purchase!
For any concerns, contact us:
help@epicgraffiti.com



See more of our art:
cozystreet.com/collections/art-all





WALL CANVAS BASIC TROUBLESHOOTING

Canvas too Loose?

On the back of the canvas, take a look at the corners. You will notice wedges in each corner. Those wedges enables you to adjust the tension. Simply, tap each wedge with a hammer. Read on to learn more.




Stand your art piece upright on top of a hard surface. Place a piece of cloth inbetween (to protect both the surface and your art).




Tap down on all stretcher wedges with a hammer where the arrows point. Rotate the canvas, so that you're always tapping downwards toward the hard surface. Tap until you see the frame begin to split further apart. Repeat process until canvas is stretched tightly to your liking.

Have Creases?



On the back of the canvas, rub the ice **lightly** unto the crease for about 30-60 seconds. Let it dry 15-20 minutes and the indent should fade away.



Warped Frame?

An easy fix by bending it back.

Identify your bad corner. Place the art along a table's edge. Place your hands on the corner that was coming away from the wall and its opposite corner. **Gently** push down on the corners to stretch the canvas diagonal. Test the frame by hanging your art back up. If it's still coming away from wall, repeat steps.

TIP: It is normal to hear the wood slightly splintering.