



INSTRUCTION MANUAL

WARNING

 **Please read the instructions carefully and follow the assembly steps.**

To ensure proper assembly, please follow all steps and use all parts provided. Not following this warning may result in serious injury to you or others.

To prevent misalignments, keep the screws loose and do not tighten them until they are all in their correct positions.

Avoid overtightening or forcing the screws, as this could cause them to break, strip, or damage the threads of the holes.

Using the wrong size of screws for a particular part could cause damage to the screw or the part.

Please lubricate all moving parts regularly and tighten all bolts and screws every 6 months, or as needed.

SAFETY INFORMATION

WEIGHT CAPACITY FOR SEATING: 250 LBS



Sit in the center of the chair with your back against the backrest



Do not sit at the front edge of the chair



Do not stand on the chair



Do not use the chair with more than one person



Do not push the chair around when a person is sitting in it



Do not push down on the backrest when a person is reclined



Do not place all your weight on the backrest only

ASSEMBLY PARTS AND TOOL

BEFORE YOU GET STARTED, A FEW POINTERS:



Having a friend to help makes assembly extra-easy



Please use the included wrench instead of an **ELECTRIC HAND DRILL** in case of damage to the chair leg.

A



Seat Cushion *1

B



Back Cushion *1

C



Upper Leg *1

D



Lower Leg *1

E



Front wood strip *1

F



Back wood strip *1

G



Middle wood strip *1

H



X-Metal plate*1

I



M6*20mm Bolt * 6

J



M6*60mm Bolt * 4

K



M4*35mm wood screw * 6

L



Spring washer * 4

M



Flat washer *4

N



Allen Wrench *1


ASSEMBLY INSTRUCTIONS



Note: Please prepare 1pc cross wrench before assembly.

Step 1

Install upper leg C and lower leg D, then put the X-metal plate on the bottom of the legs cross connection, using Four **M6*20mm Bolts I**, tighten the bolts to 50% by Allen Wrench N.




ASSEMBLY INSTRUCTIONS

Step 2

Attach the front strip E, back strip F and middle strip G to the leg frame.


Note: Please pay attention to the screw holes direction on the strips, below line-drawing for your reference.



ASSEMBLY INSTRUCTIONS

Step 3


Insert Six **M4*35mm wood screws K** into the screw holes, using your own Cross Wrench to tighten the screws to 50%.



ASSEMBLY INSTRUCTIONS

Step 4


Attach the seat cushion A with the finished wood frame, using Four **M6*60mm Bolts J**, Spring Washer L and Flat Washer M, then tighten by Allen Wrench N to 50%.



ASSEMBLY INSTRUCTIONS

Step 5


Attach the back cushion B to the finished frame, using Two **M6*20mm Bolts I**, tighten by Allen wrench N to 50%.



ASSEMBLY INSTRUCTIONS


Step 6

Tighten all the screws to 100%.



Step 7

Adjust the foot nails to level the chair. Now, your chair is successfully installed.



LIMITED WARRANTY

We promises to repair or replace any chair that is found to be defective in material or workmanship within one year from the date of original purchase so long as you, the original purchaser, still owns it. This is your sole and exclusive remedy. This warranty is subject to the provisions below.

EXCLUSIONS

This warranty does not apply and no other warranty applies to:

- Normal wear and tear, which are to be expected over the course of ownership.
- Misuse, abuse, or excessive use of the product.
- Modifications or attachments to the product that are not approved by us.
- Products that were not installed, used, or maintained in accordance with product instructions and warnings.
- Products used for rental purposes or unauthorized retail activities.

Seating Usage: Normal use for seating is identified as the equivalent of a single shift, forty- (40) hour workweek. To the extent that a seating product is used in a manner exceeding this, the applicable warranty period will be reduced in a pro-rata manner.

RETURN POLICY

We adopt a 30-day return policy which means that all products purchased on this website may be returned to us within the timeframe. You need to contact us within 30 days after the product(s) came into your possession and the product(s) must be returned to us without any undue delays.

Returned products must be returned in the same condition as they were sent and they must be sent in their original packaging.

If the product is not faulty, (i.e. if you changed your mind or if you are unhappy with the product for some other reason), the cost of shipping will fall on you. And it is your responsibility that the package arrives safely to us so we recommend that you use a courier service where it is possible to track the shipment.

LIMITED WARRANTY

If the product is faulty when you receive it, please contact us and we will help you out.

We reserve the right to give a partial refund in cases when the product(s) is not in an unused condition, is damaged or has missing parts, not due to our error.

HOW RETURNS WORK

To request a return, please fill out the contact form on our website and attach a copy of your invoice as proof of purchase and the reason for your return in the message.

Then we will provide the return address for the product as soon as possible.

Once the returned product has been received by us and inspections have been completed, a specific disposition will be provided to you.

In addition, if the return is approved, the refund amount will be automatically credited to your original payment method.