

Assembly Manual Shoe Storage Bench





Exploded View



Warnings

ATTENTION:

FUNCTION OF KLIX CAM




1/2 RIGHT TURN FOR LOCKING


MAKE SURE THE ARROW OVER AGAINST THE TOPSIDE OF CAM LOCK PIN BEFORE INSERTING INTO THE PANEL'S HOLE

IMPORTANT!

After 180° right turn, if there is a gap between the boards, please check whether the cam lock pin is tightened enough.




Components List







Components List



TIPS:


- 1. When installing the product, usw a soft surface (such as carpet or cardboard) to avoid scratching or damaging the surface of product.
- 2. Please try to use a manual screwdriver instead of electric screw driver. A manual screwdriver can be used to better control the tighness of the screws.
- 3. Do not use any glue.
- 4. The product is unstable before it is assembled. Please pay attention to the product installation sequence, and align all screws and screw holes before tightening.
- 5. The structure of this product can not meet the requirements of climbing.









Insert board(6) into slots on boards(1&2&3) as shown below.





















STEP 9


Insert board(11) into slots on boards(8&12). Then lock it using Klix cams(C). Regarding the usage of Klix cam, please refer to warning on Page 2.









STEP 11 Attach board(19) to board(11) and lock by Klix cams(C).














STEP 15 Insert board(15) into slots on board(9&10&13).



























Fix the other end of the angle iros(H1) to the top plate as STEP 23 shown in the figure and lock them with screws (H2).





Warning

- Please keep the product away from children while assembling.
- Do not let children play orjump on the product.
- Do not stand on the item or use it as a step ladder.
- Prior to use, please check for any loosening screws or parts.
- Make sure that each screw and part is correctly installed and securely fastened.

Care and Maintenance

- •Use a soft clean cloth that will not scratch the surface when dusting.
- •There's no need to use furniture polish, you need to, test it first in an inconspicuous area.
- •Using solvents of any kind on your furniture may damage the finish.
- Never use water to clean your furniture as it may cause damage to the finish.
- Liquid spills should be removed immediately.
- Gently blot the spill with a soft, clean cloth to avoid rubbing.

Further advice about the furniture care

- •It is best to keep your furniture in a climate-controlled environment.
- Extreme temperatures and humidity changes can cause fading, warping, shrinking and spitting of wood.
- We recommend keeping furniture from sunlight exposure to avoid possible surface damage.
- Proper maintenance and cleaning at home will extend the life of your purchase.
- Following these important and helpful tips will help retain your furniture's performance even it ages.
- Periodically (every 90 days), make sure the screws are fully tightened.

- Please check all the hardware and furniture before assembling.
- If anything is missing, please feel free to contact us. If you
 only leave a message on the platform, we may not be
 able to effectively solve the problem.
- Timely communication helps us understand your situation
- and provides you with the best shopping experience.

Have a question for our company?

Thank you for supporting our company.

- If you have any issues with your purchase, please feel free to let us know.
- We will always do our best to work out a solution that you will be happy with.

Length of return period:

Items can be returned within 30 days of receipt of shipment. Who is responsible for the return shipping fee?

We will cover the return shipping fees if:

- 1. The item received is damaged or defective.
- 2. The wrong item was shipped to you.
- 3. The item received is materially different from what was described on the product page.
 - If the return is for any other reason, the customer will be responsible for the return shipping fees.

However, we always hope to work with you to find a better solution instead of a return. Please don't hesitate to contact us.

If the return is due to reasons other than the ones listed above, the customer will be responsible for the return shipping fees, if:

- 1. You are not satisfied with the product(s) after receiving the box(es).
- 2. You no longer need the product(s), but you have already received the box(es).
- 3. You purchased the product(s) by mistake, but you have already received the box(es).
- 4. Before FedEx picks up the package, please make sure that everything is returned 1 to the original packaging and that the prior opening will not affect the reselling of the product.

You can try to get Amazon prepaid labels for UPS express return. Alternatively, we can provide prepaid shipping labels after you provide photos of the package before and after repackaging. Just stick the label on the box and call FedEx to pick it up.

When will I be refunded?

The refund will be issued once the goods have been received and processed at our warehouse. If you have any questions, please don't hesitate to contact us, and we will work with you to find a solution that ensures your satisfaction.