




INSTALLATION

Product Manual




IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.





AVOID SCRATCHES!

In order to avoid scratching this furniture should be assembled on a soft layer-could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !




It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.



Please prepare the following tools




When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 93



CRB1595A

B x 93




CRA0635A

C x 43




CRF0630A

D x 37




CRC0540A

E x 8




DGA861A

F x 4



DGA861B

G x 5




WX1014A

H x 94



CRD3514A

J x 11




K x 62




CRD3512A


L x 2



M x 2




N x 2




CRD3535A

P x 5



Q x 5




CRD555A

R x 20





CRE3514A



S x 5



Option A



Option B




⚠ WARNING







Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.


*This is a permanent label.
Do not remove!*




1





As shown, screw the self-tapping rod (B) into Panel 4.





Flip to back, screw the self-tapping rod (B) and fix part (S-1) with screws (H).








2

B x 12  CRA0635A	H x 16  CRD3514A	S x 4  S-1	
---	---	---	---


As shown, screw the self-tapping rod (B) into Panel 3.
Use screws (H) to fix the part (S-1) to Panel 3.






3






As shown, use wooden tenons (C) to connect Panel 1 and Panel 2 to Panel 4, and then fix them with screws (D).



4





As shown, use the wooden tenon (C) to connect Panel 5 to Panel 4, and then insert the eccentric wheel (A) and rotate it clockwise to tighten.



5




As shown, use the wooden tenon (C) to connect Panel 3 to the assembled unit, and then insert the eccentric wheel (A) and rotate it clockwise to tighten.




6




R x 20
CRE3514A





As shown, use screws (R) to connect back Panel 6 and Panel 11 to the assembled unit.



7




As shown, install the corner brace hanging device.






Pay attention to the difference between the middle parts of the two types of door hinges.

- The full coverage door hinges(E) are used on the outermost door plates
- And the curved door hinges(F) are used on the door panel in the middle of the cabinet.








E




F




9




As shown, use screws (H) to install the hinges (E) onto Panel 7 and Panel 10.



10




As shown, use screws (H) to install the hinge (E) onto Panel 3.



11


J x 2




K x 4






CRD3512A




As shown, use screws (K) to install the handles (J) onto Panel 7 and Panel 10.



12



As shown, use screws (H) to install the hinges (F) onto Panel 8 and Panel 9.




13

H x 16



CRD3514A



H




CRD3514A

K




CRD3512A

As shown, use screws (H) to install the hinge (F) onto Panel 4.



14



J x 2




K x 4




CRD3512A





As shown in the figure, use screws (K) to install the handles (J) onto Panel 8 and Panel 9.



15







16




As shown, screw the self-tapping rods (B) into Panel 13 and Panel 14.


Use screws (K) to fix slide rails (G-CL) and (G-CR) to Panel 13 and Panel 14.



17





As shown, use the wooden tenon (C) to connect Panel 19 to Panel 13, and then insert the eccentric wheel (A) and rotate it clockwise to tighten.




18

A x 6
CRB1595A




C x 2
CRF0630A









As shown, use the wooden tenon (C) to connect Panel 14 to the assembled unit, and then insert the eccentric wheel (A) and rotate it clockwise to tighten.






19

B x 4  CRA0635A	G x 4  WX1014A	K x 16  CRD3512A	
--	---	---	---


As shown, screw the self-tapping rods (B) into Panel 15 and Panel 16.
Use screws (K) to fix slide rails (G-CL) and (G-CR) to Panel 15 and Panel 16.






20




As shown, connect Panel 15 and Panel 16 to Panel 18, and then insert the eccentric wheel (A) and rotate it clockwise to tighten.





21






Option A




As shown, use the wooden tenon (C) to connect Panel 17 to the assembled unit, and then fix it with screws (D).




22



Option B




As shown, use the wooden tenon (C) to connect Panel 17 to the assembled unit, and then fix it with screws (D).




23

Option A




Insert Panel 31 and Panel 32 along the available slots.




24


Option B




Insert Panel 31 and Panel 32 along the available slots.






25



As shown, screw the self-tapping rod (B) into Panel 12.
Use screws (H) to install the part (L).






26



Option A

As shown, use the wooden tenon (C) to connect Panel 12 to the assembled unit, and then insert the eccentric wheel (A) and rotate it clockwise to tighten.




27

A x 8




CRB1595A

C x 8






CRF0630A



Option B

As shown, use the wooden tenon (C) to connect Panel 12 to the assembled unit, and then insert the eccentric wheel (A) and rotate it clockwise to tighten.




28

A x 16





CRB1595A

B x 16




CRA0635A






As shown, screw the self-tapping rod (B) into Panel 20.


Connect Panel 20 to Panel 21, and then insert the eccentric wheel (A) and rotate it clockwise to tighten.



29



As shown, screw the self-tapping rod (B) into Panel 17.




30

A x 16




CRB1595A



C x 4



CRF0630A



As shown, use wooden tenons (C) to connect Panel 20 and Panel 21 to the assembled unit, and then insert the eccentric wheels (A) and rotate them clockwise to tighten.



31




M x 2



N x 2



CRD0555A



Option A



N




CRD3535A

Q




CRD0555A


As shown, install the anti-tipping device.




1.





2.



3.



4.



32




M x 2



N x 2



CRD0555A



Option B



N




CRD3535A

Q




CRD0555A


As shown, install the anti-tipping device.




1.





2.






3.




4.



33



As shown, screw the self-tapping rods (B) into Panel 22 and Panel 23.





34

A x 15




CRB1595A



As shown, connect Panel 26, Panel 27 and Panel 30 to Panel 22, and then insert the eccentric wheel (A) and rotate it clockwise to tighten.

Insert Panel 29 along the available slot.





35

A x 10




CRB1595A




As shown, connect Panel 26, Panel 27 and Panel 30 to Panel 23, and then insert the eccentric wheel (A) and rotate it clockwise to tighten.

Insert Panel 29 along the available slot.




36

D x 25
CRC0540A




As shown, use screws (D) to connect Panel 26 and Panel 27 to Panel 28.



37

G x 5
DL
DR
WX1014A

K x 20
CRD3512A






As shown, use screws (K) to fix the slide rails (G-DL) and (G-DR) to Panel 26 and Panel 27.




~~H~~
CRD3514A

K
CRD3512A



38


J x 5




K x 10





CRD3512A



As shown in the figure, use screws (K) to install the handles (J) onto Panel 22 and Panel 23.




x3



x2

Option A


As shown in the figure, insert the drawers to the main body part.





40



Option B

As shown in the figure, insert the drawers to the main body part.




41

E x 4  DGA861A	H x 8  CRD3514A	
---	--	---

	H  CRD3514A	K  CRD3512A
	E  DGA861A	F  DGA861B

As shown, use screws (H) to install the hinges (E) onto Panel 24 and Panel 25.




42

H x 16



CRD3514A



Option A



H




CRD3514A

K



CRD3512A

As shown, use screws (H) to install the hinges (E) onto Panel 13 and Panel 14.




43

H x 16



CRD3514A



Option B



H




CRD3514A

K




CRD3512A

As shown, use screws (H) to install the hinges (E) onto Panel 13 and Panel 14.



44


J x 2



K x 4



CRD3512A




CRD3514A




CRD3512A

As shown, use screws (K) to install the handles (J) onto Panel 24 and Panel 25.



45


J x 2



K x 4



CRD3512A



Option B




CRD3514A





CRD3512A

As shown, use screws (K) to install the handles (J) onto Panel 24 and Panel 25.




Option A



47

Option B



WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.
- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.
- The product must be used in accordance with the instructions provided. For health reasons.
- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.
- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.
- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.
- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOUR ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.