



## User's Manual for 1.91/2.75 Cubic Ft White Keypad Fireproof Jewelry Safe

Read all instructions before using this safe.




### WARNING

- For security purposes, change the factory default code as soon as possible. Factory default code is 123456.
- Test registered pin code a few times before closing the safe door.
- Avoid leaving door open and unattended; it will allow unauthorized individuals to reprogram the safe, gaining full access to the safe and its contents.
- Do NOT store combustible materials in this unit.
- In the event of a fire, we recommend caution when opening the safe. If you feel unsure about opening the safe because of the contents stored, contact your local fire department for assistance.
- Test the emergency keys and store them in a secure place; NOT inside of the safe.
- Test and make sure the safe works properly before mounting.
- Mount the safe before use, the safe may tip forward if not properly mounted.
- Keep children away from safe; they should not play with or around the safe at anytime. Children at play could accidentally get locked inside the safe or accidentally pull on the safe door causing safe to tip over if not properly mounted.
- Failure to follow these warnings could result in serious injury or death.

NOTE: BARSKA is not responsible for any damage or lost contents in the safe due to moisture.

NOTE: BARSKA is not responsible if the safe and its contents gets lost or stolen.

### PARTS OF THE SAFE



- A. Bolts
- B. Key Hook
- C. Reset Button
- D. Motion Sensor Light
- E. Jewelry Drawer

- F. Keypad and Keypad Cover  
- turn keypad counter clockwise to expose Battery Compartment and Emergency Key Access
- G. Indicator Lights
- H. Handle

### BATTERY & KEY ACCESS

\*To operate the safe, please install one 9V Alkaline battery (not included).

Push down on button located under the key pad and turn keypad cover counter clockwise.

DO NOT pull on the wires or touch the electronic components.

#### Install Battery

Insert one new 9V alkaline battery into the battery compartment and restore keypad cover.


#### Key Access

Turn the key clockwise and the handle the unlock position to open the safe. The key slot is located behind the keypad.

\*\*Test the Emergency Keys and store them in a secure place; NOT inside the safe.

### MOTION SENSOR LIGHT

1. Motion Sensor Light has Velcro and magnet bar at rear, so it can attach on the carpeted interior or metal surface of the safe. Before you start to use the safe, please remove the light from the safe and install with 4 AAA batteries (not included).




2. Motion Sensor Light should be automatically activated when the safe door is opened each time. If not, please wave your hand to activate the light. Light should turn off within a delay time after the safe door is closed.

### PIN CODE REGISTRATION

Safe retains 1 pin code (3 to 8 digits) Safe Factory Default PIN Code :123456

#### Changing PIN Code

1. Insert original PIN code (for 1st time use, the original PIN code is default PIN code) and press "#". Then, the green light will turn on.
2. During the duration of green light on, press "\*" and then the yellow light will turn on as well. You can change to your desired PIN code now.  
NOTE: If you don't take any action after 8 seconds, the safe will be back to standby mode.
3. Enter your desired PIN code and press "\*". You will hear two beeps and the yellow light will turn off. This means you have registered your PIN code successfully.  
NOTE: If you hear 4 beeps, it means you didn't register your PIN code successfully. Please, repeat the above steps again.



## OPENING AND CLOSING SAFE WITH PIN CODE

### Open

1. Enter the registered PIN Code and press “ # ” to confirm.
2. When the green light is on, turn the handle clockwise to the unlocked position and pull safe door open.

### Close

Close the safe door and turn the handle counter-clockwise to the locked position.

## RESET TO FACTORY DEFAULT MODE

Press hold the reset button until one beep and yellow light turns on.

The safe is in factory default mode after reset; Factory PIN Code: 123456.

## LOCK OUT MODE

After 3 consecutive incorrect PIN Code attempts, safe will be in lock-out mode with beeping sound for 20 seconds. You can enter the correct PIN Code after the lock-out mode.

## LOW BATTERY WARNING

If a red light turns on while accessing and using the safe, this indicates that the batteries are low, please replace battery as soon as possible.

## MOUNTING INSTRUCTIONS

The safe may be mounted down to the floor. Beware of the load bearing. Failure to do so can result in personal injury and/or damage to property. Use appropriate tools when performing work and always use eye protection.

### Floor Mounting

- Use proper drill tools depending on the type of floor you are mounting the safe (wood, tile, concrete).
- Measure the location of the pre-set drill holes; mark their exact position onto the floor.
- Drill the appropriate size holes for the anchors you are using.
- Carefully press the anchors into the holes at this time.
- Mount the safe by running screws from the inside of the safe and securing to anchors; ensure the safe is mounted securely.

## - CARE AND MAINTENANCE

- Keep liquids away from the control panel. Spills on the control panel will cause damage and possibly electric shock.
- Secure safe in a proper area to prevent from falling and causing damage or injury.
- DO NOT disassemble the product. For all repairs and maintenance, contact BARSKA Customer Service.
- DO NOT use chemicals or cleaning agents to clean the safe.



## 1 YEAR LIMITED WARRANTY

### FIRE SAFE VAULTS

BARSKA warrants this new safe to be free of original defects in material and/or workmanship under normal use for a period of twelve (12) months from the date product is received by purchaser. This warranty does not include damage caused by improper installation or maintenance. Damage from misuse, abuse, accident (such as dropping), fire, flood, or acts of nature. Damage from service or repairs other than those performed by BARSKA. Labor, cost and shipping charges for the removal and replacement of defective parts beyond the initial twelve-month warranty period. All transportation and shipping charges. Removing or altering the seal under any circumstances will automatically void the warranty.

This warranty is limited to original purchaser and is not transferable. This warranty applies only to products purchased in the United States.

Please email [info@barska.com](mailto:info@barska.com) or call 1.888.666.6769 for Return Merchandise Number (RMA#) before any returns. The RMA number must appear on the outside of the shipping package. Product must be packed carefully and sturdily in its original packaging to prevent damage in transit and returned freight pre-paid to:

BARSKA OPTICS  
Repair Department  
855 Towne Center Drive  
Pomona, CA 91767

Please include all of the following when returning BARSKA products for service and/or replacement:

1. Please write your complete details (Name, Address, Telephone #, E-mail address, RMA#, etc.)
2. Purchase receipt or Proof of Purchase. (Original/Copy)
3. A brief explanation of the defect.

\*Please allow 6-8 weeks for delivery.

BARSKA will examine and test returned product and repair or replace defective part(s) or units with new part(s) or a new unit if necessary within the warranty period.

If repair is required after warranty period expiration, purchaser will be charged for replacement parts and return shipping.

BARSKA® Optics shall not be liable for any consequential, incidental and/or contingent damages whatsoever. We will not pay shipping, insurance or transportation charges from you to us, or any import fees, duties and or taxes. This warranty supersedes all previous BARSKA® warranties.