


TV Stand

Assembly Instructions - Please keep for future reference



Dimensions

Width-66.929inch

Depth-15.748inch

Height-27.165inch



WARNING



This product is NOT a Clothing Storage Unit (CSU).
DO NOT use it for clothing storage.
Improper use may cause furniture tipover.

Important - Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor.

- Parts of the assembly will be easier with 3 people.



power drill is set on a low torque setting.

- To reduce the likelihood of damaging your product please ensure that your

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.

- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts

- Regularly check and ensure that all bolts and fittings are tightened properly.

WARNING
In order to help prevent overturning –
please follow these instructions








To help prevent product toppling over please follow the below steps:-

Use the anti tip strap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

Components-Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required

(A)  6*35mm Cam Bolt x 36	(B)  15*10mm Cam Lock x 36	(C)  8*30mm Dowel x 12	(D)  4*40mm Screw x 8
(E)  3.5*14mm Screw x 70	(F)  Layer plate support x 8	(G)  Anti-tilt Angle iron x 2	(H)  6*21mm Door stop x 4
(I)  Phillips screwdriver x1	(J)  Back panel buckle x 20	(K)  Plastic expansion bolt x 2	(L)  EVA pad x 9
(M)  Metal handle x 4	(N)  4*18mm Screw x 8	(O)  Hinge x 8	

Tools required



Phillips screwdriver


Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.
NE PAS SERRER EXCESSIVEMENT.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




Step 4

Turn the female camlock clockwise with a screwdriver.


You should feel a click when the camlock is locked in place.








The joint is now secure.

4




Assembly Instructions




 1700*400*15mm ①X1	 1700*400*15mm ②X1	 590*399*15mm ③X1	 590*399*15mm ④X1
 820*260*3mm ⑤X2	 590*399*15mm ⑥X1	 582*402*15mm ⑦X2	 582*402*15mm ⑧X2
 810*360*15mm ⑨X2	 364*70*15mm ⑩X2	 1695*70*15mm ⑪X1	 1695*70*15mm ⑫X1
 812.5*86*15mm ⑬X2	 364*70*15mm ⑭X1	 820*260*3mm ⑮X2	

Assembly Instructions

Step 1




(A)



6*35mm Cam Bolt x 8

Step 2



(B)




15*10mm Cam Lock x 4

Step 1


Step 2

Step 3




Assembly Instructions

Step 3




Step 4




Assembly Instructions

Step 5





Step 6






Assembly Instructions

Step 7








Step 8








Assembly Instructions

Step 9




Step 10




Assembly Instructions

Step 11




Step 12




Assembly Instructions

Step 13



A





6*35mm Cam Bolt x 6




6*21mm Door stop x 4

Step 14



©



Anti-tilt Angle iron x 2

Ⓔ




3.5*14mm Screw x 2


Assembly Instructions

Step 15



Step 1



Step 2



Step 3



(B)



15*10mm Cam Lock x6

Step 16

(E)




3.5*14mm Screw x 20

(J)




Back panel buckle x 20




Assembly Instructions

Step 17




Step 18



Assembly Instructions

Step 19




(E)




3.5*14mm Screw x 16

(O)




Hinge x 8

Step 20



(M)



Metal handle x 4


(N)




4*18mm Screw x 8

Assembly Instructions


Step 21



If the door can't close, please adjust the hinges.



This is used to
adjust the door
panel in the up and
down direction.



Ⓔ




3.5*14mm Screw x 16

This is used to adjust the door panel in the front and back
direction: Loosen the screw first, and then tighten screw
after adjusting the door panel to the proper position.



Assembly Instructions

Step 22



If the door can't close, please adjust the hinges.

This is used to
adjust the door
panel in the up and
down direction.



E



3.5*14mm Screw x 16

This is used to adjust the door panel in the front and back
direction: Loosen the screw first, and then tighten screw
after adjusting the door panel to the proper position.

Assembly Instructions

Step 23

