


U-shape Burl Wood Coffee Table



After-sales mailbox:
Homefurniture Serviceteam@outlook.com

NOTICE

Please keep these instructions for future reference.

Dear Customer

● Thank you for your purchase. When you receive the product, please make sure that all the parts are intact. If any parts are missing, please contact us promptly to request replacement parts.

● Then follow the entire installation instructions to install.

● Each part is crucial, so please be careful not to lose any. It is recommended to store parts with different lettered identifiers in separate boxes or bags to avoid confusion during installation.

A . The outer box is damaged

B . The product is damaged / bent / cracked while you open the box

C . The parts / accessories / assembly tools are missing

D . The instructions are not clear and can not be referred

E . The product has functional problems












F . Other aspects that you are not satisfied with


Please feel free to contact us for help. Our after-sales team service

(**Homefurniture Serviceteam@outlook.com**) will reply within 24 hours and will do our best to resolve the problem for you.



PART LIST

A Table board  ×1	B Side panels  ×2	C Wooden tenon  ×4	D Full-tooth screw  ×6	
E Hexagon nut  ×6	F Spring spacers  ×6	G Flat spacers  ×6	H Half moon spacer  ×6	I Hexagon wrench  ×1
J Connect  ×4	K screws  ×16			




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

STEP


1

1. Wooden tenon **C** is shown in the corresponding **B** hole, Full-tooth screw **D** is tightened in hole **B** as shown in the figure.
2. Once the timber tenon **C** and the full thread screw **D** are installed, insert them into the corresponding holes in the **A** panel.
3. Place the half-moon spacer **H** into the corresponding card slot.



2

1. Insert the **G** flat gasket **F** spring gasket **E** hexagon nut into the **D** full-tooth screw according to the diagram arrangement, tighten it with an **I** hex wrench, connect the iron **J** plate corresponding to the pilot hole, and lock it with the wood screw **K**



AFTER-SALE SERVICE

If you have any suggestions for our products or find that the products have quality problems, please contact us first, our after-sales team will reply you within 24 hours, and we will do our best to give you solutions until you are satisfied.

Guaranteed Customer Service

Your shopping experience is very important to us!
Feel unsatisfied? **Contact us!**
Have any questions? **Contact us!**

Wanna share how wonderful our smart products make your home?

Share your pictures with us.
Any suggestions? **Contact us!**
We will check and give feedback!



Homefurnitureserviceteam@outlook.com

