


LED Lights Switch

Winding Mode

Power Supply: 100-240V Global Use.
Open the door and stop rotation,
automatic rotation of closed door.
LED light Switch: Control the LED light
The two knobs control the two motors



Winding Mode/Wickelmodus/Mode d'enroulement/Modalità di avvolgimento/Modo de bobinado
Mode 1:OFF
Mode 2:Rotate 2 min clockwise, Rest for 6 min, Repeat.
Mode 3:Rotate 2 min counter-clockwise, Rest for 6 min, Repeat.
Mode 4:Rotate 2 min clockwise, Rest for 6 min, 2 min counter-clockwise, Rest for 6 min, Repeat.
Mode 5:Rotate 5 min clockwise and 5 min counter- clockwise. Work 3 hours, Rest 9 hours, Repeat.

DE
Modus 1: AUS
Modus 2: 2 min im Uhrzeigersinn drehen, 6 min ruhen, wiederholen .
Modus 3: 2 min gegen den Uhrzeigersinn drehen, 6 min ruhen, wiederholen .
Modus 4: 2 min im Uhrzeigersinn drehen, 6 min ruhen, 2 min gegen den Uhrzeigersinn drehen, 6 min ruhen, wiederholen .
Modus 5: 5 min im Uhrzeigersinn und 5 min gegen den Uhrzeigersinn drehen. 3 Stunden arbeiten, 9 Stunden ruhen, wiederholen .

FR
Mode 1 : DÉSACTIVÉ
Mode 2 : 2 min de virage à droite et 6 min de pause, répétition.
Mode 3 : 2 min de tours en arrière et 6 min de repos, répétez.
Mode 4 : 2 minutes dans le sens des aiguilles d'une montre et 6 minutes de pause, puis 2 minutes dans le sens inverse des aiguilles d'une montre et 6 minutes de pause, répéter.
Mode 5 : 5 min de tours à droite et 5 min à l'envers. Travail 3 heures et pause 9 heures. Répéter.

IT
Modalità 1:OFF
Modalità 2: Ruotare di 2 minuti in senso orario, riposare per 6 minuti, ripetere.
Modalità 3: Ruotare di 2 minuti in senso antiorario, riposare per 6 minuti, ripetere.
Modalità 4: Ruotare 2 min in senso orario, riposare per 6 min, 2 min in senso antiorario, riposare per 6 min, ripetere.
Modalità 5: Ruotare 5 min in senso orario e 5 min antiorario. Lavora 3 ore, riposa 9 ore, ripeti.

ES
Modo 1: APAGADO
Modo 2: 2 min de vueltas al derecho, y 6 min de pausa,repite.
Modo 3: 2 min de vueltas al revés, y 6 min de pausa,repite.
Modo 4: 2 min de vueltas al derecho y 6 min de pausa,luego 2 min al revés y 6 min de pausa,repite.
Modo 5: 5 min de vueltas al derecho y 5 min al revés.Trabaja 3 horas y pausa 9 horas.Repite.

FAQ


Q: I can't find my power adapter!
A: Adapter is embedded in the foam packaging in a black box.

Q: My watch winder does not turn on.
A: Check that the ac adapter is plugged into the inlet of your winder tightly and that the outlet you use is working. Some adapters come equipped with an LED light indicating that they are working. Lastly, check that your power switch on the back of your winder is switched in the on (I) position.

Q: My watch winder has stopped working after several minutes.
A: Winder operates intermittently. Please review rotation information and observe the winder as it should start again. Other-wise, refer to the second question.

Q: By watch winder does not wind my watch.
A: Watches should be fully wound previous to being placed in the winder. Check that your watches are compatible with bi-directional automatic watch winders and refer to watch instruction manual on the winding information.

Q: My watch does not fit around the pillow.
A: Remove the pillow (S) from the slots on the winder. Close watch strap or bracelet and squeeze the pillow in (horizontal position).You should then be able to insert your watch with the pillow into the slots on the winder. If you have a smaller size strap or bracelet, you can remove the stuffing from the pillows to accommodate for the size.



Self-stop
with the door
open

⚠ CAUTION:

- 1.Please use the adaptor included with your watch winder or similar adaptor with exact same voltage output.
- 2.Please do not manually spin the winder. This will damage you watch winder and void your warranty.
- 3.Avoid exposing the watch winder to direct sun, water or other moisture, and extreme temperatures which may damage the watch winder.