



## USER'S MANUAL Hanging Hammock Swing Tent

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

**Please give us a chance to make it right and do better!**

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP!

EN | DE | FR | ES | IT | PL

---

# Contact Us!

## Do NOT return this item.

Contact our friendly customer service department for help first.

# Before You Start

Please read all instructions carefully and keep it for future reference.

### Warnings:

**Attention:** For home use only.

**Attention:** The Product is not suitable for the children under 3 years

**Danger:** Keep all small parts and packaging materials for this product away from babies and children, otherwise they may pose a choking hazard.

**Danger:** Lack of attachment may cause a risk of tipping or fall hazards.

### General Warnings:

- ⚠ The product must be installed and used under the supervision of an adult.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ Remove all packaging, separate and count all parts and hardware.
- ⚠ Please ensure that all parts are correctly installed, incorrect installation can lead to a danger.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Ensure a secure surface during construction, and place the product always on a flat, steady and stable surface.
- ⚠ Please check and maintain regularly, the most important parts for suspension, fixing, anchoring to the ground.



### IMPORTANT

READ AND FOLLOW ALL SAFETY INFORMATION AND INSTRUCTIONS, KEEP FOR FUTURE REFERENCE

WARNING! CHOKING HAZARD-SMALL PARTS, NOT FOR CHILDREN UNDER 3 YEARS. WARNING! MAXIMUM WEIGHT SHOULD NOT EXCEED 100KGS.

WARNING! DO NOT USE WITHOUT ADULT SUPERVISION!

WARNING! ADULT ASSEMBLING REQUIRED!

### ESSENTIAL INFORMATION

-Recommended for children 3+ years

-Do not leave child unattended while in use

-CAUTION: Use only under adult supervision

-Good safety practices should be followed at all times

-Read all instruction before using this product.

Intended solely for family and domestic use, not for a commercial playground or daycare. Two adults needed for assembly. Maximum weight capacity: 100KGS.

Hanging hardware not included. Ideally, the swing body should be hung over

grass, sand, wood chips, or other soft surfaces. Under no circumstances should it be hung over concrete, asphalt, or other hard surfaces. Distance from ground should not exceed 40cm; the maximum fall height should not be more than 46cm, Two S hooks are attached to the rope to allow for adjustment of the rope length.

Please be sure to examine the ropes regularly to check for wear. Rope will, in time, degrade. If the color of the rope has become pale, frays easily, or gives off a powdery material when rubbed between the fingers, we recommend you replace the rope.













Equipment should be hung in such a way that a distance of at least 2m is clear on either side. Can be hung on an A-frame or swing set or on a tree limb of a diameter of at least 25cm.




**WARNING! Small parts need to be assembled by an adult.**

Tools Required (included in the packaging)



## Swing Assembling

		
<p>1. Swings arrives in 4 pieces, and 2 hanging ropes, a jump body for assembly.</p>	<p>2. Put the jump body on the floor, and put the 4 velcros to the black mat direction</p>	<p>3. Put the 4 metal tubes with foam into the sleeves one by one.</p>
		
<p>4. Put the tube like this.</p>	<p>5. Put 2nd tube to the sleeve, small socket to the big socket of the 1st tube, and connect it.</p>	<p>6. Repeat it, and make it like half folded as the pic.</p>
		
<p>7. Then connect the body as a round platform.</p>	<p>8. Assemble the screw bolt, first put it through the velcro belt.</p>	<p>9. Screw bolt goes through the velcro belt cover.</p>
		
<p>10. Assemble the screw bolt to the tube of the frame.</p>	<p>11. Tighten it with the screw nut, do not forget the washer.</p>	<p>12. Use the wrench to tighten it before use.</p>

		
<p>13. After the bolt assembling, and cover the velcro belt, and repeat 3 times on other 3 bolts.</p>	<p>14. Top appearance as the pic shows.</p>	<p>15. Assembly is finished, and ready for swing.</p>

## Tent Assembling

1. Lay the cover on swing surface. The four openings are facing to four hanging ropes.



2. Lock the buckle on the bottom of the opening. Repeat this 3 times one by one.



3. Pull the rope and pass through the ring on top of the swing. Then go through the black plastic buckle on the rope like pictures shows. And repeat it for the other rope.



4. The length of the rope is adjustable. Adjust it to a suitable height. The assembly is finished.



---

## **Ensuring Safety of the Swing**

Clearance distance should be 4m around the swing.

A fall onto a hard surface can result in serious injury to the equipment user.

Do not use the equipment until properly installed.

This swing is not to be used in any other manner other than its intended use. Adult supervision is required.

Adults should verify that the hanging ropes are secured and cannot be looped back on the swing.

It is important for adults to instruct children to:

-Dress appropriately while using the swing (avoid ponchos, scarves, and other loose-fitting clothing that is potentially hazardous)

-Sit in the center of the swing with full weight on the seat if swinging alone

- Avoid swinging empty seats
- Do not lean heavily on the sides of tent
- Never lean on the gate of tent

It is important for adults to instruct children NOT to

-Walk close to, in front of, behind, or between moving items

-Twist ropes or loop them over the top support bar since such action may reduce the strength of the rope

-Get off the sing while it is in motion

-Climb on the swing when it is wet.

-Attach additional items to the swing that might cause a strangulation hazard.

-Wear a bicycle or sport helmet while on the swing.

## **Maintaining the Swing**

At the beginning of each play season, adults should:

- Tighten all hardware.
- Tighten all the buckles of tent

-Check all protective coverings on pipes, edges, and corners, and replace them if they are loose, cracked, or missing.

-Check all moving parts including swing seat, ropes for wear, rust, or other deterioration. Replace as needed. The hardware used for this swing (binding post, screw, S hook, lock washer, flat washer, and metal ring) can be found at local hardware store.