


# PLEASE READ THE INSTRUCTIONS



**Styles and colors may vary**

- ◎ Suitable age for 3-8 Years
- ◎ Maximum user weight: 59kg
- ◎ Adult assembly required

**INSTRUCTION  
MANUAL**



Charge for 4-6 hrs  
before initial use.

After initial charge,  
follow the normal  
recommended  
Charging time.



## **SAFETY**

Please retain these instructions for future reference.

**NOTE:**For best performance,only use this vehicle on flat and hard surfaces.

**AGE RANGE:**3 to 8 years old

**WEIGHT CAPACITY:**59KG is the maximum weight for 1 rider(combined)

The following safety hazards may result in serious injury or death:

- This product contains small parts.Keep children away during assembly.Make sure to remove all packaging material and parts from underneath the vehicle body.
- Never open the battery.Batteries contain lead and lead compounds(acids).
- Limbs,hair,and clothing can get caught in moving parts.Always wear shoes,keep limbs away from moving parts,and do not wear loose clothing while operating this vehicle.
- This vehicle does not have brakes or braking capability.Do not leave a child unattended during operation.DO not use this in a location that may require braking capability.as this could result in loss of control,which may cause serious injury or death.
- Use of this vehicle near streets,motor vehicles,steps,bodies of water,sloped surfaces,hills,wet areas,flammable vapors,in alleys,at night,or in the dark could result in an unexpected accident.
- Use of this vehicle in unsafe conditions such as snow,rain,loose dirt,mud.sand,or gravel may result in an unexpected accident such as tipping over,and could damage the electrical system or battery.
- Do not operate this vehicle in an unsafe manner.Examples include but are not limited to:
  - pulling the vehicle with another vehicle or similar device
  - Allowing more than two children to ride
  - Pushing the user
  - Traveling at an unsafe speed
- The battery charger used with the electric toy shall be regularly examined for damage to the supply cord, plug, enclosure or other parts, and in the event of damage, it shall not be used until the damage has been repaired.

## BATTERY WARNINGS

The following safety hazards may result in serious injury or death:

- Use of a battery or charger other than the supplied rechargeable battery and charger may cause a fire or explosion. Only use the supplied battery and charger.
- Use of the rechargeable battery and charger for any other product may result in overheating, fire, or explosion. Never use the supplied rechargeable battery and charger with another product.
- Explosive gases are created during charging. Charge the battery in a well-ventilated area. Do not charge the battery near heat or flammable materials.
- Contact between the positive and negative terminals may result in fire or explosion. Avoid direct contact between the terminals. Picking up the battery by the wires or charger can cause damage to the battery and may result in a fire. Always pick up the battery by its case or handles.
- Liquids on the battery may cause fire or electric shock. Always keep all liquids away from the battery and keep the battery dry. Contact or exposure to battery leakage (lead acid) may cause serious injury. If contact or exposure occurs immediately call your physician. If the chemical is on the skin or in the eyes, flush with cool water for 15 minutes. If the chemical was swallowed, immediately give the person water or milk. Do not give water or milk if the patient is vomiting or has a decreased level of alertness. Do not induce vomiting.
- Battery posts, terminals, and related accessories contain lead and lead compounds (acid)
- Tampering or modifying the electric circuit system may cause a shock, fire or explosion and permanently damage the system. Exposed wiring and circuitry in the charger may cause electric shock. Always keep the charger housing closed.

## USER WARNINGS


The following safety hazards may result in serious injury or death:

- Never leave a child unattended.
- Always sit in the seat when using this vehicle.
- Keep your hands, hair, and clothes away from moving parts.
- Always wear shoes when operating this vehicle.
- Maximum of two children are allowed in the vehicle at a time.
- Children under 3 years of age cannot use the vehicle.
- Only drive on level ground.
- Do not go near swimming pools or other bodies of water, drop-offs, or up and down steep inclines.
- Do not drive the vehicle into loose dirt, mud, sand, fine gravel, or on wet surfaces.
- Do not drive the vehicle on streets or near cars.

## SPECIFICATIONS

| Item       | Specification                        |
|------------|--------------------------------------|
| Batteries  | 12V / 24V                            |
| Motor      | 12V / 24V                            |
| Age        | 3-8years                             |
| Max Weight | 59KG                                 |
| Dimension  | 113×66×72CM                          |
| Speed      | 3-8km/hr (24V) / 2-4km/hr (12V)      |
| Play Time  | 1-2 hours / recharger time 8-12hours |
| Charger    | Output DC 24V                        |
| Charger    | Output DC 12V                        |

## TOOLS REQUIRED



SCREWDRIVER  
(BRING YOUR OWN)



M10 WRENCH  
(PROVIDED)



2 PERSON  
ASSEMBLY



APPROXIMATELY  
45 MIN.  
ASSEMBLY

## HARDWARE

1

M4\*12mm  
SCREW



4 PCS

2

$\phi$  12 GASKET



6 PCS

3

M10 NUTS



6 PCS

4

$\phi$  10 WASHER



2 PCS

5

BEARING  
(OPTIONAL)



2 PCS

6

SPRING  
(OPTIONAL)



2 PCS

## PARTS

A


REAR WHEEL



2/4 PCS

B


WHEEL COVER



4 PCS

C


STEERING WHEEL



1 PCS

D


FRONT BUMPER



1 PCS

E

GEAR BOX (L/R)



2 PCS

F


REAR AXLE



1 PCS

G

BACKREST




1 PCS

H

SEAT





1 PCS



## PRODUCT ASSEMBLY

① ① **D** Fix the front bumper


- Clip the front bumper into the body.
- Fix with screws.



# 12V/24V Dual drive (Optional) (Subject to the actual purchase configuration)


## ⑥ ① ② Fix the dual drive front bracket

- Insert spring and spring sleeve into the dual drive front bracket.
- Insert the dual drive front bracket into the body square tube.



## ③ ④ Fix the dual drive front bracket

- In turn put the  $\phi 10$  washer and nut into the dual drive front bracket.
- Fix the nut with the M10 wrench.




(Subject to the actual purchase configuration)

5

I

Fix the four drive front bracket

- Insert bearing into the four drive front bracket.
- Insert the four drive front bracket into the body square tube.




(Subject to the actual purchase configuration)


3 4

Fix the four drive front bracket

- In turn put the  $\phi 10$  washer and nut into the four drive front bracket,
- Fix the nut with the M10 wrench.




As shown in the figure:Connect the motor wires.



## PRODUCT ASSEMBLY


### F Fix the rear axle

- Insert the rear axle into the car.



### E Fix the gear box (L/R)

- Put the drive motor into the rear axle, and stuck the motor into the body slot. (Tips: gear box left right distinction)




# 12V/24V Dual drive (Optional)

(Subject to the actual purchase configuration)

Put the gasket, front wheel, gasket and nut into the front axle in turn.

Fix the nut with the M10 wrench and then attach the wheel cover to the wheel



Place the Rear wheel, gasket, and nut on the rear axle in turn.


Fix the nut with the M10 wrench and then attach the wheel cover to the wheel.

# 12V/24V Four drive (Optional)

(Subject to the actual purchase configuration)

Put the Rear wheel, gasket and nut into the front axle in turn.

Fix The nut with the M10 wrench and then attach the wheel cover to the wheel





Place the Rear wheel, gasket, and nut on the rear axle in turn.

Fix the nut with the M10 wrench and then attach the wheel cover to the wheel.


## PRODUCT ASSEMBLY

- C** Fix the steering wheel.
- Remove the nut and bolt from the steering wheel.
  - Insert the steering wheel over the steering and secure with nut and bolt.



Open the seat



Find the main power cord under the seat, and insert the plug of the power cord into the corresponding socket of the receiver. The plug of the drive motor cable is docked with the plug on the receiver (the plug on the receiver is not differentiated left and right).



## PRODUCT ASSEMBLY

### I Fix the seat.


- Clip the seat into the body.
- Rotate the latch on the seat to secure the seat.




## PRODUCT ASSEMBLY

**G** Fix the backrest.

- Clip backrest into the body.




## DASHBOARD DIAGRAM




1. Pedal button: Step on the button , the car will move when release,the car slowly stop
2. Control board:

## DASHBOARD DIAGRAM



3. Power button: Long Press it 3 seconds, Turn the vehicle on and off.
4. Wireless Technology: After connected your mobile phone and the wireless device, the car can play music from your mobile phone.
5. F: Radio, long press it 2-3 seconds, the light of FM button will flash and Automatic search, when the search completes, the FM key stops flashing.
6. Music Button: play music.
7. Last song: Switch songs/and long press will decrease volume.
8. Forward button: Press it, go forward.
9. Backward button: Press it, go backward.
10. Speed button: Press it, choice high speed or low speed.
11. Next song: Switch songs/and long press will increase volume.
12. U.
13. Socket: charge.
14. Power display: Clearly see the battery power, in order to charge in time.

## CHARGING INSTRUCTIONS



1.Insert the charger jack into the charging hole of the car.

2.Plug the charger plug into the stable matching AC power supply as shown in the picture.

- Charge the battery 15 to 18 hours before initial use.
- On average,you will need to charge the battery between 8 and 12 hours.Do not charge the battery for more than 20 hours.Failure to charge the battery as directed could cause permanent damage to the battery and void the warranty
- Damage to the battery may occur if it is allowed to drain completely.Do not allow the battery to drain completely.
- Check the battery and charger (supply cord,connector) for wear and damage before charging.DO not charge the battery if damage has occurred.
- Only an adult who has read and understood the safety warnings should handle,charge and recharge the battery.

## CARING FOR YOUR RIDE-ON

- Park the vehicle indoors or cover it with a tarp to protect it from wet weather.
- Do not leave the vehicle in the sun for long periods of time or fading may occur.  
Store in shade or cover with tarp.
- Do not wash the vehicle with a hose.
- Do not wash the vehicle with soap.
- Charge battery at least once a month to prolong the life of the battery.

## TROUBLESHOOTING

| PROBLEM   | REASON                                      | SOLUTION   |
|---|---|--|
| Vehicle does not move                                   | Low battery                                 | Fully charge the battery   |
|   | Electrical protection                       | Stop use for several minutes and restart                               |
|   | Switch not in the correct position          | Completely press in switches   |
|   | Battery connectors disconnected             | Plug in battery connectors   |
| Battery does not recharge                               | Battery connectors disconnected             | Plug in battery connectors   |
|   | Charge not connected to socket or outlet    | Completely plug in the charger   |
| Battery does not last                                   | Battery does not have a full charge         | Fully charge the battery   |
| Battery is warm and makes a slight noise while charging | Normal                                      | Normal   |
| Slow speed  | Low battery                                 | Fully charge the battery   |
|   | Overloaded vehicle                          | Reduce the weight on the vehicle                                       |
|   | Uneven or sloped road                       | Drive on flat pavement   |
| Vehicles shakes while driving                           | Loose connection to motor                   | Ensure the motor is properly connected to the battery                  |
| Difficulty shifting between forward/reverse             | Attempting to shift while vehicle in motion | Only shift when the vehicle is at a stop                               |
| Forward and reverse switch is flipped                   | Gear boxes are installed incorrectly        | Make sure the L gear box is on the left and R gear box is on the right |

## WARNINGS REGARDING BATTERIES

The battery on the vehicle is not replaceable.

- DO not mix old and new batteries.  
DO not mix alkaline,standard(carbon-zinc),or rechargeable batteries.
- Non-rechargeable batteries should not be charged.
- Rechargeable batteries should be charged under adult supervision only.
- Exhausted batteries should be removed.
- The supply terminals should not be short-circuited.
- Do not put batteries next to or in a heat source(fire,electronic heating device,etc.)
- Do not hit batteries against hard objects.
- Do not submerge batteries in water.
- Batteries should be inserted with the correct polarity.
- Only use the battery specified by the manufacturer.
- Only use the charger specified by the manufacturer.



### WARNING:

- Protective equipment should be worn.Not to be used in traffic.
- The toy should be used with caution since skill is required to avoid falls or collisions causing injury to the user or third parties.
- To reduce the risk of injury,adult supervision is required.Never use in roadways.near motor vehicles,on or near steep inclines or steps,swimming pools or other bodies of water;always wear shoes,and never allow more than 1 rider.



**WARNING:** ADULT ASSEMBLY REQUIRED



**WARNING:** Not to be used in traffic



**WARNING:** CHOLING HAZARD-Small parts.

Not for children under 3yrs.

## IMPORTANT

- Always charge battery for a FULL 18hrs the first time you use it.
- Always charge battery for a FULL 10hrs after each use.
- Charge the battery once a month. even if you are not using your vehicle.

## FCC Statement

### Caution:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference. (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.