


Instruction Manual



Functions

1. LCD time display;
2. Alarm and 10 minutes snooze function;
3. Talking function: report current time;
4. Backlight;
5. CHIME1: telling time every hour; CHIME2: telling time only from 7:00am to 9:00pm.
6. Five alarm sounds;
7. Projection show time;

Operations

1. Battery installation

Remove the battery compartment door and insert 3 AAA batteries into it.

2. Under any mode, press top key to tell the time with backlight and projection on for about 10 seconds. (When it connects to external power, the backlight and projection will be on all the time.)

3. Under normal mode, press MODE key to enter the following modes respectively.

Normal time—Time setting—Alarm setting—ALM and CHM on/off.

Under time setting mode, press MIN/SOUND key to adjust minutes, press HR to adjust hours.

4. Alarm setting

Under normal time display, press MODE key twice to enter the alarm setting mode, then press MIN/SOUND key to adjust minutes, press HR to adjust hours.

5. ALM and CHM on/off


Under normal time display, press MODE key three times to enter the ALM and CHM setting mode, then press MIN/SOUND key to turn on/off the alarm function. When the alarm function is on, the mark will display. Press HR key to turn on/off the chime function. The following set modes will display respectively:

CHM1 ON—CHM2 ON—CHM OFF

When the CHM1 function is on, the mark will display. When the CHM2 function is on, the mark will display.

6. Under normal time display, press MIN/SOUND key to choose the alarm sounds. Press HR/12-24 key to switch 12HR/24HR time mode. Press the key for 2s to switch °C/°F.

使用说明书



功能：

1. LCD时间显示；
2. 闹钟和10分钟贪睡功能；
3. 语音播报：读取当前时间；
4. 背光灯；
5. 响闹1：每天整点报时；响闹2：每天上午7点至晚上9点整点报时；
6. 五种闹铃铃声选择；
7. 投影显示时间；

操作：

1. 电池安装

打开电池门，放入3节AAA电池。

2. 在任意模式下，按顶部键背光显示时间，同时投影显示10秒。（电源外接时，背光及投影一直显示。）

3. 在正常模式下，按MODE键依次进入以下模式：

正常模式—时间设置—闹钟模式—闹钟、响闹开关。在时间设置模式下，按MIN/SOUND键调整分钟，按HR键调整小时。

4. 闹钟设置

正常时间显示模式下，按MODE键两次进入闹钟设置模式，然后按MIN/SOUND键调整分钟，按HR键调整小时。

5. 闹钟和铃声开关

在正常模式下，按MODE键三次进入闹钟和响闹设置，然后按MIN/SOUND键打开或关闭闹钟功能。如果闹钟功能开启，图标会出现。按HR键打开或关闭响闹功能。以下设置模式将依次呈现：

响闹1开启—响闹2开启—响闹关闭

当响闹1开启，图标将会显示。当响闹2开启，图标将会显示。

6. 在正常模式下，按MIN/SOUND键选择铃声。按HR/12-24键转换12/24小时制，长按此键2秒转换°C/°F。