


Assembly Instruction - Please keep for future reference

SIDEBOARD



Dimensions

Length-48.82inch

Width-15.75inch

Height-32.28inch

Important – Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.


- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor.

- Parts of the assembly will be easier with 2 people.



power drill is set on a low torque setting.

- To reduce the likelihood of damaging your product please ensure that your

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.

- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts

- Regularly check and ensure That all bolts and fittings are tightend properly.

WARNING

In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-

Use the anti tip stap or wall fixing method provided (if applicable)

Do not allow children to climb or hang on the furniture

Do not open more than one drawer at a time









Do not place heavy items in the top drawers

Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose



Components - Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A1  Cam lock x 10	A2  Cam bolt x 10	A3  Cam cap x 10	B  8*30mm Dowel x 12
C  6*50mm Screw x 2	D  Allen key x 1	E  3.5*16mm Screw x 36	F  4*32mm Screw x 2
G  16mm Nail x 26	H  Metal Shelf Support x 8	I  5/8 PVC Nail Leg x 4	J  Hinges x 6
K  Handle Screw M4 x 3	L  Handle x 3	M  Sofa Leg x 2	N1  Wall support x 4
N2  3.5*16mm Screw x 2	N3  4*35mm Screw x 2	N4  Cable tie x 2	

Tools required




Philips screwdriver
(medium & large)

Using Camlocks


Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




Step 4

Turn the female camlock clockwise with a screwdriver.









You should feel a click when the camlock is locked in place.

The joint is now secure.




Components - Parts


Please check you have all the panels listed below

① 	② 	③ 
Top Panel 1240*400*15 1 PC	Bottom Panel 1178*383*15 1 PC	Side Panel (L) 800*384*15 1 PC
④ 	⑤ 	⑥ 
Side Panel (R) 800*384*15 1 PC	Center Panel 755*383*15 1 PC	Back Panel 1207*784*2.5 1 PC
⑦ 	⑧ 	⑨ 
Shelf Panel (L) 773*360*15 1 PC	Shelf Panel (R) 389*360*15 1 PC	Door Panel 745*381*20 3 PCS


Assembly Instruction





STEP 1





STEP 2





STEP 3





STEP 4




STEP 5




STEP 6




STEP 7




F  4*32mm Screw x 2	M  Sofa Leg x 2
--	--

STEP 8




I  5/8 PVC Nail Leg x 4

STEP 9




(H)




Metal Shelf Support x 8

STEP 10





STEP 11




(K) 	(L) 
Handle Screw M4 x 3	Handle x 3

STEP 12



(E) 	(J) 
3.5*16mm Screw x 12	Hinges x 6

STEP 13




(E)




3.5*16 Screw x 24

HINGE ADJUSTMENT GUIDE


It may be necessary to adjust the hinges so that the doors align.
Use the instructions below as a guide.



To adjust the door horizontal loosen the screw as shown by turning clockwise or anti-clockwise.




To adjust the door vertically loosen the screw as shown and move up and down as needed.




To adjust the gap from the door to the main frame turn the screw clockwise or anti-clockwise as needed.

STEP 15



N1




Wall support x 2

N2




3.5*16mm Screw x 2

STEP 16




N1




Wall support x 2

N3



4*35mm Screw x 2

STEP 17



STEP 18

