

CAUTION








Parts are placed at the bottom of the product

Your recliner comes packaged in one box . Carefully remove all of components from the packaging and set aside for assembly .

CAUTION:


DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result .

Package Contents


			
A x 1 Chair Seat	B x 1 Left Chair Arm	C x 1 Right Chair Arm	D x 4 Wooden Leg
			
E x 2 Plastic Center Leg	F x 8 Allen Bolt M6*10 mm	G x 1 Open Wrench M4	H x 4 Washer Leg

Assembly Instructions


STEP 1 : Assemble the chair on a flat and soft surface either on a carpet or cloth to prevent the finish from scratching.




STEP 2 : Assemble the chair on a flat and soft surface either on a carpet or cloth to prevent the finish from scratching. To locate the hardware , please turn the chair (A) upside down, you will find the components beneath the fabric cover that is secured by a velcro strap underneath the seat cushion. Lift the strap upwards, legs and hardware could be located beneath the fabric cover.



STEP 3 : Insert the Arm (B and C) the Chair Seat (A) hard side as below.




STEP 4 : Turn the chair over and place it upright on a level surface.
Assembly is complete.




ATTENTION!!

Bolts may loosen during normal everyday use. They should be periodically inspected and re-tightened to prevent damage or injury. Always check to ensure that all hardware is kept tightened.

FUNCTIONS :



The steps to adjust the sofa to bed



Warnings

1. Please check if the components of the chair are all included and can be used normally.
2. Assemble all components according to the instruction correctly.
3. If the chair is damaged or doesn't match the website description, please send clear pictures of the product and label of the carton to our service team for further help.