


TOUGH TOOLS, HALF PRICE

WASHER AND DRYER COUNTERTOP USER MANUAL

We continue to be committed to provide you tools with competitive price. "Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually Saving Half in comparison with the top major brands.

WASHER AND DRYER COUNTERTOP



NEED HELP? CONTACT US!

This is the original instruction, please read all manual instructions carefully before operating. We reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

SAFETY INSTRUCTIONS

WARNING:

Read this material before using this product. Failure to do so can result in serious injury.

Assembly precautions


1. Assemble only according to these instructions. Improper assembly can create hazards.
2. Wear ANSI-approved safety goggles and heavy-duty work gloves during assembly.
3. Keep the assembly area clean and well-lit.
4. Keep bystanders out of the area during assembly.
5. Do not assemble if tired or when under the influence of alcohol, drugs or medication.
6. The product capabilities apply to properly and completely assembled products only.
7. Assemble on a flat, level, hard and smooth surface capable of safely supporting the Washer and Dryer Countertop.
8. For additional information regarding the parts listed in the following pages, please refer to the Assembly Diagram of this manual. Unwrap and separate all parts in a clean work area.

Use precautions


1. DO NOT SIT OR STAND ON THIS ITEM.
2. This product is not a toy. Do not allow children to play with or near this item.
3. Do not exceed specified weight capacities.
4. Use only on a flat, level, hard, and smooth surface that can safely support a fully loaded Washer and Dryer Countertop.
5. Use as intended only.
6. Inspect before every use; do not use if parts are loose or damaged.

SAVE THIS MANUAL


PARTS LIST




1 1pc




2 1pc



3 2pcs



4 1pc



5 1pc



6 2pcs



M7X50MM

B

24pcs



M6X40MM

H

4pcs



Φ6X30MM

W

6pcs




Y

8pcs





Z

2pcs





ASSEMBLY STEP

1




x2

2




3



B x4

H x2




4





B x4

H x2



5




6



7



8



PRODUCT PARAMETER

Model			
Safe Loading Weight	250 lbs		
Colour	White	Oak+White	Black
Product Size	1370*700*419mm		