





Model: CAMELIA Typ: Rtv with fireplace Strona: Blatt Nr: 2/16


OPTION WITH A FIREPLACE




















ONLY THE STANDING VERSION









Model: CAMELIA Typ: Rtv with fireplace Strona: Blatt Nr.: 13/16


15




Model: CAMELIA Typ: Rtv with fireplace Strona: Blatt Nr. 14/16

16







PL - UWAGA!

Nasze powierzchnie o wysokim połysku są fabrycznie ochronione specjalną folią ochronną. Prosimy pozostawć ją na meblach do momentu zmontowania i usunięcia kurzu. Po usunięciu folii ochronnej pozostawić folię połyskową przez 12 godzin w pomieszczeniu do stwardnienia.

EN - ATTENTION!

Our high gloss surfaces have a protective foil when delivered. Please leave this foil on the furniture until it is completely assembled and all dust has been removed. Expose the high gloss foil to the room air for 12 hours to allow it to harden after removing the protective foil.

DE - HINWEIS!

Unsere Hochglanzoberflächen sind bei der Auslieferung durch eine Schutzfolie geschützt. Belassen Sie diese auf dem Möbel, bis es vollständig montiert und von Staub befreit ist. Der Hochglanzfolie nach der Entfernung der Schutzfolie 12 Stunden Zeit zum Nachhärten an der Raum-Luft geben.

CZ - POZOR!

Naše povrchy s vysokým leskem jsou při dodání chráněny ochrannou fólií. Ponechejte ji na nábytku, dokud nebude kompletně smontovaný a nebude z něho odstraněný prach. Po odstranění folie dejte nábytku 12 hodin čas na vytvrzení v pokojové teplotě.

SK - POZOR!


Naše vysoko lesklé povrchy sú chránené špeciálnou ochrannou fóliou. Prosím, nechajte ju na nábytku, kým nábytok nezmontujete a neodstránite prach. Po odstránení ochrannej fólie nechajte lesklý film 12 hodín v miestnosti vytvrdnúť.


HU - FIGYELEM!


Az általunk gyártott bútorok magas fényű felületei speciális védőfóliával gyárilag védettek. Kérjük a védő fóliát ne távolítsák el a bútor összeszereléséig, és a por szerelést követő eltávolításáig. Avédőfólia eltávolítását követően tartsuk a bútort 12 órán át a fóliázott felületek megkeményedésére alkalmas környezetben.

HR - PAŽNJA!

Dijelovi namještaja u visokom sjaju imaju na sebi zaštitnu foliju prilikom isporuke. Molimo vas da tu foliju ostavite na namještaju dok nije u potpunosti montiran i dok nije odstranjena sva prašina u prostoru. Nakon uklanjanja zaštitne folije dijelove namještaja u visokom sjaju izložiti sobnom zraku 12 sati.







IMPORTANT SAFETY INFORMATION ELECTRIC FIREPLACE SAFETY INFORMATION AND WARNING

ATTENTION: This Safety Information and Warning provides basic information for using an electric fireplace insert safely. Failure to follow the recommendations and warnings below may result in risk of fire, electric shock, and injury to person and property.

- WARNING! There's a risk of fire, electric shock, and injury to person if you don't follow the included
 instruction and safety information. We are not liable for any damages or injury caused by mishandling,
 improper installation, or improper use of the electric fireplace insert.
- WARNING! Prior to using your electric fireplace insert, compare the rated power of the electric fireplace
 insert to the capacity of the electrical circuit you plan to use it within. In order for the electric fireplace
 insert to be safely used, the electric fireplace insert's electrical demand, in addition to the electrical
 demand of any other electric devices using the circuit, should be well within the electrical capacity of the
 circuit. If you are unsure of the electrical capacity of the circuit, or the electrical demand of devices using
 the circuit. contact a licensed electrician for assistance.
- WARNING! Your electric fireplace insert may require a dedicated electrical circuit. Check with your local building codes.
- WARNING! To avoid electrical shock, do not open the back panel of the insert unless the power has been turned off and the insert has been unplugged.
- WARNING! The electric fireplace insert must be used on an AC supply only, and the voltage marked on the heater must correspond to the supply voltage.
- WARNING! Any repairs or modifications done to this electric fireplace insert are not recommended, and
 may cause an increased risk of fire, electric shock, and injury to person. Any repairs or modifications will
 void all warranty and technical support for this unit. If the decision of the user of the electric fireplace
 insert is to repair or modify the insert or any electrical wiring, such repairs or modifications should be
 done only by a licensed electrician, and must comply with local building codes.
- WARNING! Discontinue the use of this electric fireplace if any of the following has occurred:
 - o Water damage
 - o Insert has been damaged or dented
 - Power cord has become broken
 - Power cord has become too hot to touch
 - Insert smokes or smells like smoke (Note: When the heater function is used for the first time, a slight odor may be present. This is normal and should not occur again unless the heater is not used for an extended period of time.)
 - WARNING! Do not cover or obstruct the insert in any way. The insert will overheat if covered.
- WARNING! Never immerse the product in water or any other liquids.
- WARNING! Do not run cables under carpets or rugs. Do not allow the main cables to hang over the sharp
 edges of the electric fireplace insert. Do not allow the main cables to come into contact with hot
 surfaces. From time to time, check the cable for damage. Never use the electric fireplace insert if the
 cable or any part of the insert shows signs of damage.
- WARNING! Do not switch the electric fireplace insert on until it has been properly installed as
 described in the instruction manual. Do not leave the electric fireplace insert unattended during use.
- WARNING! Keep the electric fireplace insert out of the reach of children. Do not let children operate the electric fireplace insert.
- The electric fireplace insert is fitted with a safety cut-off which will trigger if the insert overheats (e.g. due to blocked air vents). For safety reasons, the insert will NOT automatically reset. To reset the electric fireplace insert, disconnect the insert from the power supply for at least 15 minutes. After 15 minutes, reconnect the insert to the power supply and switch the insert on.

Claim your extended 90 day product warranty by registering your product at www.meblefurniture.com/register

ATTENTION: DO NOT RETURN THIS PRODUCT!!! PLEASE READ THE FOLLOWING!!!

FOR REPLACEMENT/MISSING PARTS:

www.meblefurniture.com/parts

FOR INSTRUCTION/ASSEMBLY MANUALS AND VIDEOS:

www.meblefurniture.com/assembly

ALL OTHER INQUIRIES:

help@meblefurniture.com

IF YOU ARE MISSING PARTS OR YOUR PRODUCT ARRIVED DAMAGED:

Please fill out a parts request form at www.meblefurniture.com/parts

Replacement parts are shipped out in one business day. You will receive a tracking number via email once your parts request has been processed.

IF YOU ARE MISSING AN INSTRUCTION MANUAL OR NEED ASSEMBLY HELP:

Please visit www.meblefurniture.com/assembly to access our library of product assembly videos or to download product instruction manuals.

NOTICE REGARDING HIGH GLOSS PROTECTIVE FOIL AND PRODUCT CARE:

After removing the protective foil from the gloss fronts, the acrylic surface of the boards is still soft and easy to scratch. With air contact, the hygroscopic acrylic layer hardens, and the board becomes more resistant to scratches. It takes approximately 48 hours for the acrylic layer of the board to fully harden.

DO NOT CLEAN, WIPE, OR POLISH THE ACRYLIC FRONTS FOR 48 HOURS AFTER REMOVING THE PROTECTIVE FOIL!!!











www.meblefurniture.com help@meblefurniture.com 866-777-5105

IMPORTANT SAFETY INFORMATION WALL MOUNTING FURNITURE SAFETY INFORMATION AND WARNING

LED Light Kit Instruction Manual

What's Included in your LED Light Kit

- LED Glass Clips and/or LED Pucks LED glass clips are placed directly onto glass, and emit light throughout the glass. LED pucks are attached to the surface without the need for any tools, and provide even light distribution.
- RGB Receiver Transmits signal to the remote, allowing you to control your light settings. Your LED lights are 16 colored, and have different light settings.
- Remote Control Allows you to easily turn your lights on/off and adjust the color as desired.
- Splitter Used to connect your lights to your power supply.
- · USA Power Supply Used to power your LED light kit.

How to Install your Lights

- 1. Before installing, lay out all the products inside of the LED light kit package.
 - a. Connect each LED light to the splitter.
 - b. Connect the splitter to the RGB receiver.
 - c. Connect the RGB receiver to the power supply.
 - d. Plug the power supply into an outlet and press the ON button using the remote.
 - e. Check that everything is in working order, and then unplug your power supply & proceed with install.
- 2. If you have LED glass clips, you can clip them directly onto the back of the glass shelf. Never place LED lights where they are directly visible (on the front of the shelves), as they will be too bright.
- 3. If you have LED pucks, make sure the area where you want to attach your LED pucks is clean of dirt and debris, then attach the lights to the top of the shelves.
- 4. Finally, re-connect your power supply to the electrical outlet, and use your remote to change the lights to your desired color.
- 5. Enjoy your new TV stand lighting!

Troubleshooting

- · LED Lights Not Turning On
 - o Check your connections to make sure everything is plugged in.
 - o The issue might be with the remote (refer to "Remote Not Working" section).
- Remote Not Working
 - o Try moving closer to the receiver in case your remote is not in range.
 - o Check to see if anything is blocking the signal between the remote and the receiver.
 - Make sure the receiver is exposed when installing.
- · Request a Free Replacement LED Light Kit
 - If you are still experiencing issues after troubleshooting, you can request a replacement LED light kit shipped to you free of charge. To request a free replacement kit, please do one of the following:
 - Fill out the Parts Request form at www.mebleus.com/parts, or email help@meblefurniturerugs.com.

ATTENTION: This article provides basic information for mounting your wall mounted floating furniture to a wall using a wall mount bracket.

- WARNING! There's a risk of damage to your furniture and wall and injury to
 person if you don't follow the assembly or installation instructions correctly.
 We're not liable for any damages or injury caused by mishandling or improper
 installation of the wall-mount bracket.
- WARNING! If you use substitute items other than the supplied screws, the furniture may fall and cause physical injury to someone or damage to the furniture and/or wall.
- WARNING! Do not attempt to mount furniture that is not sold as wall mounting furniture.
- We strongly recommend that a qualified professional install your furniture on the wall for product protection and safety reasons. Sufficient expertise is required to determine the strength of the wall for withstanding the furniture's weight.
- Check the wall-mount installation manual supplied with your furniture for information on how to properly mount your furniture. Product manuals are posted on our website at https://meblefurniturerugs.com/pages/assembly.
- We don't guarantee the use of third-party wall mount brackets or screws.
- Use the screws supplied with the wall-mount bracket when you attach the wallmount bracket to the furniture.
- Any repairs or modifications done to the included wall mount bracket or any part of the wall mounted furniture are not recommended, and may cause an increased risk of damage to your furniture and wall, and potentially injury to person. Any repairs or modifications will void all warranty and technical support for this unit.

SAVE THIS SAFETY INFORMATION AND WARNING FOR FUTURE REFERENCE