



SAFETY INSTRUCTION


WARNING

- Do not put the wet plug into the socket.
- Do not touch the plug with wet hands, etc.


ATTENTION


- Before the first connecting of the appliance, please ensure that voltage indicated on the rating label corresponds the mains voltage in your home.
- Changing the bulb is only allowed after unplugging the lamp from the power supply.
- The lamp is checked on full conformity to the quality and safety standards.
- Do not use the lamp outdoors.
- The manufacturer shall not be responsible for damage to property and personnel caused by improper use.
- If any further questions, please contact our Customer Support Team immediately.


Disassemble Diagram





Product Lists
























NOTE: Take out the lampshade from package. In order to make the shape regular, please refold the lampshade by following its four edge lines (Follow the pic).



















CUSTOMER SERVICE

30

30-Day Return Policy

If you're not completely satisfied with your purchase, simply return the merchandise via our Official Customer Support.

Unused merchandise can be refunded or exchanged within 30 days from the original purchase date.



2-Year Warranty

We guarantee your product is free from defects in product material and workmanship for two (2) years starting from the date of purchase during normal use of household conditions. If your appliance fails to operate properly within our warranty period, we will arrange a new one. Replacement is free and all shipping costs are covered.



Quick Response within 12 Hours

If you are still unable to resolve the issue you are experiencing, please contact us immediately via our support email. It doesn't matter if the product has been installed or not, our customer support team will respond within 12 hours and assist you quickly and efficiently. The most efficient way to confirm your problem to us is to attach a video, which illustrates your product issues.



COMMON TROUBLESHOOTING

Problems and Countermeasures

PROBLEM	PROBABLE CAUSE	SOLUTION
Accessories	Missing parts/Damage parts/Mismatching Boards damaged/ Boards scratch	Please contact us via after-sale email, and we will reply within 24 hours and provide you with a satisfactory solution.
	Missing plastic ring	1.Please refold 4 edges by following its crease. 2.Please contact us via after-sale email.
	Lampshade damage/ irregular	1.Please refold 4 edges by following its crease. 2.Please contact us via after-sale email.
Whole lamp	The lamp shake	 Please make sure the lamp is put on a flat and firm floor. Please do not put the lamp on the carpet, or it's necessary to put heavy items on the baseboard to keep steady.
	Diffcult installation	1.Follow the user manual/Scan QR code on user manual to watch video. 2.Please contact us via after-sale email.
	Commodity damage caused by non-human factors	If the product is damaged due to non-human causes, please keep the product and send us related photos. We will reply within 24 hours and provide you with a satisfactory solution.