

ASSEMBLY INSTRUCTIONS

VINTNER / HAROLD DINING CHAIR


ASSEMBLY REQUIREMENTS:

1-Person
Assembly

30 Minutes
Assembly Time
Per Chair
(Approximate)

Tools Required:
(Not Provided)

Phillips
Screwdriver




Thank you for purchasing our product!

Please refer and use this assembly instruction to assemble the product. Contact our customer service department in case there are any missing or damage parts or hardware. Replacement parts are normally shipped within 2 or 3 days.

Email: replacementparts@buylateral.com
Within 30 days from delivery date

We appreciate your business!



ASSEMBLY PREPARATION

1. Remove all packaging materials, staples and packing straps from the carton.
2. Refer to Parts List and Hardware List and ensure they are complete before you start assembling.
3. Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent parts from getting scratched.

SAFETY PRECAUTION:

1. KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.
2. DISPOSE PLASTIC PACKAGING MATERIAL IMMEDIATELY TO AVOID ANY RISK OF SUFFOCATION TO CHILDREN AND ANIMALS.

TIPS FOR ASSEMBLY:

1. Allow ample room for assembly and in close proximity to where product will be placed.
2. Assemble the product on a surface that does not scratch or damage the exterior gloss and finish of the furniture.
3. Please check all of the parts and quantities are included before assembly. Contact customer service for missing parts.
4. Identify all of the parts, hardware and quantities required for each step.
5. During assembly, do not over-tighten any fittings as this may cause damage.
6. DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.
7. Always place the product on a flat surface.
8. Do not sit or stand on the partially assembled product; only use the product for which it is intended.









CARE AND MAINTENANCE

- Use a slightly damp cloth to clean the product. Do not use bleach or abrasive cleaning material.
- Check all the fittings periodically and re-tighten as necessary. Do not use the product if any of the parts is damaged or broken.
- Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or delaminate.
- Do not place hot items (e.g. hot drinks) directly onto the wood surface.
- Do not drag and/or pull the furniture.

This product is for indoor and household use only - not for commercial use.



ASSEMBLY INSTRUCTIONS

VINTNER / HAROLD DINING CHAIR

HARDWARE LIST			
No	Description	Qty	Extra
A	Allen Key M4 (Short) 	1Pc	
B	Jcbc Screw M6 x 80mm 	4Pcs	1Pc
C	Jcbc Screw M6 x 60mm 	4Pcs	1Pc
D	Jcbc Screw M6 x 35mm 	3Pcs	1Pc
E	Spring Washer 1/4" 	11Pcs	2Pcs
F	Flat Washer 1/4" 	11Pcs	2Pcs
G	Wood Screw M4 x 38mm 	4Pcs	1Pc
H	Nail Leg 		2Pcs

*Extra Hardware For Spare Use

PARTS LIST		
No	Description	Qty
1	Box Frame & Seat	1Pc
2	Front Leg L/R	2Pcs
3	Back Rest	1Pc
4	Stretcher L/R	2Pcs




- Lay Back Rest (3) flat down on a material that does not scratch or damage the part.
- Place Box Frame & Seat (1) to Back Rest (3) aligning the center screw hole on (1) to screw hole on (3).
- Use Allen Key (A) to drive JCBC Screw (D) fitted with Spring Washer (E) and Flat Washer (F) to fasten (1) to (3). Do not tighten fully at this time.

ASSEMBLY INSTRUCTIONS


VINTNER / HAROLD DINING CHAIR

STEP 2



- a) Use Allen Key (A) to drive JCBC Screw (B) fitted with Spring Washer (E) and Flat Washer (F) into Screw holes on the left and right rear corner blocks of (1). Do not tighten completely until all 4X (B) are in place.
- b) Tighten all of the Screws (B & D). Do not over-tighten.
- c) Attach Right Stretcher (4R) and Left Stretcher (4L) to Back Rest (3).

STEP 3



- a) Place Left Front Leg (2L) to fit Left Stretcher (4L) and align to left front corner of Box Frame & Seat (1) as shown.
- b) Align the screw holes on corner block of (1) to (2L). Insert JCBC Screw (C) fitted with Spring Washer (E) and Flat Washer (F) into each of the screw hole on the corner block. Use Allen Key (A) to drive (C). Do not tighten (C) completely until both Screw are in place.
- c) Use the same assembly procedure in Step (3a) & (3b) above to install Right Front Leg (2R)
- d) Use Wood Screw (G) to fasten Left & Right Stretcher (4L & 4R) to Back Rest (3) and Front Leg (2L & 2R).
- e) Tighten all of the Screw in Step 3. Do not over-tighten.