

Sinber

Wall Microwave Cabinet Installation Guide

Tools Required:

Electric drill

Screwdriver

Level

Tape measure

Mounting screws (included with the product)

Support bracket or bracket (if necessary)

Wall locator (for finding the wall studs)

Preparation before installation:

Please make sure the installation location is close to the power outlet.

Please make sure the wall structure is strong and can bear the weight of the microwave and cabinet.

It is recommended that two people work together to ensure safety.

Installation steps:

Step 1: Determine the installation location

Measure the height of the bottom of the wall cabinet from the ground (it is recommended to be about 137cm-145cm above the ground).

Use a level to draw the installation line on the wall to ensure that the cabinet remains level after installation.

Step 2: Fix the installation hanging strip (if applicable)

If the cabinet is designed for hanging strip installation, please firmly install the hanging strip on the wall studs.

Drill holes in the wall with an electric drill and fix them with expansion screws.

Step 3: Install the wall cabinet

Hang the microwave wall cabinet on the hanging strip or fix it directly to the wall.

Use an electric drill to drive the screws through the cabinet back panel and fix them in the wall keel.

Use a level to confirm the cabinet level again and adjust appropriately.

Step 4: Install the microwave oven

Put the microwave oven in the dedicated space.

If the cabinet is designed with a bracket, make sure the bracket is installed and can bear the weight.

Plug the power plug into the nearest socket and organize the wires.

Notes:

Sinber

There are usually ventilation holes under the cabinet, please do not block them.

It is not recommended to install overweight microwave ovens (please refer to the cabinet load-bearing instructions).

If the wall is a gypsum board structure, be sure to drive into the keel for installation to avoid falling.

If you are not sure about the wall structure or installation method, please seek help from a professional.