


Installation Guide

Elara Rectangular Medicine Cabinet



Thank you very much for choosing our product

Tools Required for Installation




Drill



**Tape
measure**



**Safety
goggles**



**Spirit
level**




**Marker
pen**

Included Installation Hardware




Screws*5



Plastic anchors*5




Suspension bar*1



Glass shelves*2


Wall-Mounting Instructions

Step 1




Take out the suspension bar. Using the spirit level, marker pen, and tape measure, mark the mounting positions on the wall

Step 2




Drill holes at the marked locations, then insert the plastic anchors into the holes

Step 3




Install the suspension bar onto the wall. Use the electric screwdriver to tighten the screws securely

Step 4




Hang the cabinet onto the suspension bar. Use caution – make sure the cabinet is hung evenly and remains stable

Step 5



Install the glass shelves and tighten the fixing bolts firmly


Step 6



Installation Complete


Recessed Installation

Step 1




Remove the side panels of the cabinet

Step 2




Insert the cabinet into the pre-cut recess in the wall. Open the cabinet door, and using a marker pen and spirit level, mark the drilling positions on both sides of the cabinet.

Step 3




Remove the unit from the recess. Using a drill, make holes at the marked positions on both sides, then insert the plastic anchors into the drilled holes.


Step 4



Carefully reinsert the unit into the pre-cut recess. Open the cabinet door, align the holes on the cabinet sides with the corresponding holes in the wall, then insert and tighten the screws on both sides.



Step 5

Install the glass shelves and tighten the fixing bolts

Step 6


Installation Complete

Hinge Adjustment



Dimensions

SKU	Cabinet Dimensions (in/lb)				Cutout Dimensions (in)		
	W	H	D	Weight	W	H	D
Elara-1624BK	16	24	5 5/16	21.3	14 13/16	22 13/16	4 3/16
Elara-2430BK	24	30	5 5/16	33.5	22 13/16	28 13/16	4 3/16
Elara-3630BK	36	30	5 5/16	48.5	35	28 13/16	4 3/16



Scan to watch the product video



Scan to submit a service request

For more support contact: ***cswanze@outlook.com***