

WF-A188

Ice shaving machine

User's manual



Trust Come From Quality

WF-A188 Trust Come From Quality

List of different parts



Technical parameter

Body size	350X290X430MM
Packaging size	430X330X510MM
Power supply	220v-50Hz/110v-60Hz
Rated current	3.5A
Rotation amount	1400R/M
Rated power	250W
Amount of shave ice	120KGS/H
Amount of casting ice	6KG
Net weight	14KG
Gross weight	16KG

WF-A188 Trust Come From Quality

Usage instruction

1. Open the machine lid, clean and mop the ice slot with drycloth. Check whether knives are firmly fixed.
2. Check power cord and plug. SEE whether somewhere of them is broken, electricity loss or well connected. Turn off the switch and then plug in.
3. Open the machine lid, cast in proper ice then close the lid.
4. Turn on the switch.
5. According to your need, adjust the knife-adjustment handle.
6. The best diameter of ice cube is 3-5cm. You can also shave bigger ice cube into smaller one.

Notice Items

1. Single-phase 220V/50Hz volts is a must.
2. The machine lid has secure defensive equipment. If you press the on-off button without covering the lid, the machine won't work.
3. Place the machine somewhere smooth. Evenly casting ice is required. Otherwise it may cause the machine shaking.
4. The amount of cast ice should be restricted 1 cm below the up-edge of the red line of the ice slot.
5. Only dry cloth is allowed to mop the ice slot. No water.
6. Clean the water inside the ice slot after shaving ice.
7. While cleaning, avoid touch the knives in case of hurt fingers.
8. Never disassemble the machine while cleaning.