

VERSA CUSTOMER CHAIR HAI-CUCHR-11804



Product Description

- Made for customer comfort
- Ergonomically designed for back and leg support
- The extra padding and sleek vinyl leather makes for a cozy seat while offering a fresh style for any type of salon
- Adjustable arms for customer customization
- Multiple color available: Cappuccino, Cream and Coffee



Product Dimensions

- Arm-to-arm (outside): 28"
- Arm-to-arm (inside): 20"
- Back height: 28"
- Seat width: 19 1/2"
- Seat depth: 20 1/2"
- Seat-to-arm: 8"
- Adjustable height: 19" - 23"
- 5-star-base width: 28"
- Chair height (from ground to the back top): 43" - 47"

Product Parts & Installation



① 2- Armrests

② 1- Base

③ 1- Pump

④ 8- Long Screws, 8-Screw caps, 4- Short Screws and 4- Washers

⑤ 1- Seat Bracket

⑥ 1- Pump Cover

⑦ 5- Casters

⑧ 1- Seat

⑨ 1- Backrest

Step 1:
Insert the casters into the base



Step 2:
Put the bottom of the pump
(wide end first) through the
center hole of the 5-star base,
and put the pump cover on the
pump



Your Versa Customer Chair will
look like this after Step 2.



Step 3:

Take the seat bracket, line up the holes to the holes on the bottom of the seat



Step 4:

Use the four short screws to securely attach the seat bracket to the bottom of the seat



Step 5:

Tighten the screws using the Allen wrench provided



Caution:

- ① Be sure that the front arrow on seat bracket points to the front side (curve-out side) of the seat
- ② Put the washers on the screws before putting the screws into the holes
- ③ Make sure not to tighten the screws until all four screws are inserted into the holes



Step 6:

Line up the two holes on the armrest to the holes on the corresponding side of the seat

Step 7:

Use the two long screws to attach the armrest to the side of the seat



Caution:

Be sure the armrest points to the front of the seat

Step 8:

Tighten the screws with the Allen wrench provided after both two screws are inserted into the holes

Step 9:

Repeat Step 6-8 on the other side of the seat



Step 10:

Place the back of chair between the armrests

Step 11:

Use the remaining 4 long screws to screw the armrests to the backrest



Caution:

Be sure that the front of the backrest faces the seat

Step 12:

Tighten the screws with the Allen wrench provided after all four screws are inserted into the holes



Step 13:

Use the 8 screw caps to cover the screws





let your salon and spa journey begin

Step 14:

Place the seat on top of the stool pump and press down on the seat until the pump locks into the base



Congratulations!

You have yourself a

Versa Chair!



AYC GROUP

Office: 972.926.6488 | Fax: 972.926.6477
4009 Distribution Dr | STE# 225 | Garland, TX 75041