

JJFTL8R4USHS8 User Manual

Operation Steps of the Chocolate Fondue Fountain:

1. Firstly, turn on the [heating switch] 10 minutes in advance to preheat (**the temperature is set to a maximum of 110°C/230°F**), and adjust the temperature to the maximum value (**the actual temperature inside the basin is only about 40°C/104°F**). The chocolate will quickly solidify when cold, which will cause the machine to malfunction, so turn on the temperature to the maximum. After the [heating switch] is set to the maximum value, the light will automatically turn off, indicating that it is in a constant temperature state and the [heating switch] cannot be turned off during operation. After preheating for ten minutes, turn on the [rotary switch].
2. Pour the completely melted chocolate sauce into the fountain machine, and the amount of chocolate sauce should exceed half of the basin, approximately 1500ml/63oz. (Please choose a chocolate sauce with good fluidity. If the chocolate sauce is thick, it will not form a continuous fountain. You can add 1-2 small spoons of edible oil to dilute it, making the chocolate sauce more silky and smooth.)
3. If it does not achieve the desired waterfall effect, you can check whether there is enough chocolate input or adjust the balance screw at the bottom of the machine for balance adjustment until the effect is satisfactory.
4. Due to the heating function of it, it is recommended to use it continuously for 8-10 hours each time as the optimal state.

Cleaning Steps:

1. Shutdown: First please adjust the temperature to 0 °C/32°F, and then turn off the temperature control switch and rotary switch.
2. Please place the stainless steel tower and spiral rod in warm water at 50-60 °C(122-140°F) for cleaning.
3. Please wet the soft cloth with warm water and drain it before wiping the body.
4. Please wipe the entire body with a dry cloth and store it in a dry place for future use.

Precautions:

1. Please do not add blocks or solid chocolates.
2. After use, please thoroughly clean and dry according to the cleaning steps before storing.
3. The cleaning water's temperature should be between 50-60 °C(122-140°F), and it is strictly prohibited to exceed 90 °C/194°F to avoid damaging the components.
4. It is strictly prohibited to place the body in water for cleaning.