

ASSEMBLY INSTRUCTION

Thank you for purchasing this quality product.

This Magnifier Lamp is ideal for precise work in home, office workshop as well as a lot of other important places. Before using your lamp, please read the following precautions and instructions thoroughly.

Important Safety Instructions:


Place the lamp indoor dry area only. Never leave the lens unattended in direct sunlight or where light can shine through lens, it may cause fire hazard.
If the electrical cord is damaged, please contact a qualified electrician.

- **Specification:**

Magnifier: 7.5" * 6.2", 5 Diopter

Voltage: AC 110V 60Hz

Light Source: 2*9 W energy-saving compact fluorescent lamp (PL-9)



- **Assembly the lamp:**

1. Carefully unpack the packaging and place them on a carpet/flat/smooth surface.
Be sure to remove all the packaging materials from the lamp.

*Do not plug into the electrical outlet when installing or replacing bulb

2. Place Lamp Body on the top of the Base.
3. Plug power cord into power outlet.
4. Turn ON/OFF switch located next to the magnifier glass.
5. Move magnifier to the desired position

- **Change Bulbs:**

Turn off the magnifier lamp and unplug from the power outlet.

Take off the light bulb protector, replace the broken light bulbs with new one, then put the bulb protector back.

- **Care for magnifying glass:** Use dry cloth to wipe out any dust, if the glass get foggy, use some white vinegar will help

ASSEMBLY INSTRUCTION

Thank you for purchasing this quality product.

This Magnifier Lamp is ideal for precise work in home, office workshop as well as a lot of other important places. Before using your lamp, please read the following precautions and instructions thoroughly.

Important Safety Instructions:


Place the lamp indoor dry area only. Never leave the lens unattended in direct sunlight or where light can shine through lens, it may cause fire hazard.
If the electrical cord is damaged, please contact a qualified electrician.

- **Specification:**

Magnifier: 7.5" * 6.2", 5 Diopter

Voltage: AC 110V 60Hz

Light Source: 56 pcs SMD LED



- **Assembly the lamp:**

1. Carefully unpack the packaging and place them on a carpet/flat/smooth surface.
Be sure to remove all the packaging materials from the lamp.

2. Place Lamp Body on the top of the Base.
3. Plug power cord into power outlet.
4. Turn ON/OFF switch located next to the magnifier glass.
5. Move magnifier to the desired position

- **Care for magnifying glass:** Use dry cloth to wipe out any dust, if the glass get foggy, use some white vinegar will help

ASSEMBLY INSTRUCTION

Thank you for purchasing this quality product.

This Magnifier Lamp is ideal for precise work in home, office workshop as well as a lot of other important places. Before using your lamp, please read the following precautions and instructions thoroughly.

Important Safety Instructions:

Place the lamp indoor dry area only. Never leave the lens unattended in direct sunlight or where light can shine through lens, it may cause fire hazard.
If the electrical cord is damaged, please contact a qualified electrician.

- **Assembly the lamp:**

1. Carefully unpack the packaging and place them on a carpet/flat/smooth surface.

Be sure to remove all the packaging materials from the lamp.

2. Put **Rolling Leg (2)** across on the **Rolling Leg (3)**.
3. Put **Pipe (1)** into the hole on the **Rolling Leg (2)**.
4. Screw the **Pipe (1)** on to **Rolling Leg (3)** with **Screw (6)**, **Washer (5)**, and **Spring Washer (4)**

5. Place Lamp Body on the **Pipe (1)**, and tighten with the provided screw.

6. Plug power cord into power outlet.

7. Turn ON/OFF switch located next to the magnifier glass.

8. Move magnifier to the desired position

- **Specification:**

Magnifier: 7.5" * 6.2", 5 Diopter

Voltage: AC 110V 60Hz

Light Source: 56 pcs SMD LED

- **Care for magnifying glass:** Use dry cloth to wipe out any dust, if the glass get foggy, use some white vinegar will help

