




To deodorize the chair, leave it in a shaded and well-ventilated outdoor area for 1-2 days.



For long-term use, periodically retighten all bolts with the provided Allen Key and wrench. Do not use an electric screwdriver, as it may damage the chair. Always tighten the bolts manually.



Safety Information



Sit in the center of the chair, with your back to the backrest



Do not sit at the front edge of the chair



Do not stand on the chair



Do not use the chair with more than one person



Do not push the chair around when a person is sitting in it



Do not push down on the backrest when a person is reclined

INSTRUCTION MANUAL

Model: C-6010

✉ HJ-Customer-Service@outlook.com

☎ (909)637-7665 | (909)637-7593

INSTRUCTION MANUAL


C-6010




✉ HJ-Customer-Service@outlook.com

☎ (909)637-7665 | (909)637-7593

EST 9:00AM--17:00PM




Package List



(A)*1 Backrest



(B)*1 Seat



(C) *2 Crossed Foot



M6x20mm
(D) *4 Bolts



M6x25mm
(E) *1 Bolts




M6x45mm
(F) *4 Bolts




(J) *1 Hex Key


Assembly Instruction




- 1** Invert the crossed foot (C) and insert bolts (E)*1 into the bolts hole in the middle of the crossed foot. Use wrench (J) and secure one with a bolt.



- 2** Attach the crossed foot (C) to the seat (B), make sure the arrows on the foot (C) are in the same direction as the arrow on the seat (B), then tighten with wrench (J) and bolt (F)*4.



- 3** Use a wrench (J) and bolts (D)*4 to install the crossed foot (C) onto the backrest (A).



- 4** Congratulations! You have completed the installation!

CAUTION:

- * Before using the chair, make sure all bolts are fully tightened.
- * Lubricate moving parts and check all bolts every 6 months, or as needed.