

# LUMINOSA

H A N D M A D E

## Care of Luminosa™ lamps

- It is suggested that the lamps should be cleaned at least once a month to avoid moisture accumulation.
- The lamps have to be cleaned only with a damp cloth, it is suggested to use the brand "MOP", do not require aggressive products such as bleach, glass cleaner or other.
- The lamps must never be cleaned with any abrasive element (fibers, sponges, sandpaper, etc.).
- The lamps must not be exposed to any acid or cleaning product.
- In the case of copper lamps, for a more advanced care they can be protected only with a wax spray, in this case the only one we recommend is "Pledge shaker" or natural wax for wood.
- If the lamps are not cleaned at least once a month for one to two years they may begin to show a change in coloration to greenish tones, the copper will not have any other alteration except for the change in coloration.



T. + 52 415 566 4359  
E. hola@studioluminosa.mx

[www.studioluminosa.mx](http://www.studioluminosa.mx)