


**NutriHeat Silk Proteins Straightener**  
with Silk Protein Shine Infusion Therapy Technology



**Model :KS118**

**NutriHeat Silk Proteins Straightener**



Nutriheat silk protein capsules



1. NutriHeat Silk Proteins Straightener with Silk Protein Shine Infusion Therapy Technolog
2. Model No.:KS118
3. 110-240V 50/60Hz 16W

1

**DANGER**

As with most electrical appliances, electrical parts are electrically live even when switch is off.  
To reduce the risk of death by electric shock:

- Always unplug this appliance from the electrical outlet immediately after using.
- Do not use while bathing or in the shower. Do not place or store this appliance where it can fall or be pulled into a tub or sink.
- Do not place or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water.
- Unplug it immediately. Unplug this appliance before cleaning it.

**WARNING**

To reduce the risk of burns, fire, electric shock or injury to persons:

- An appliance should never be left unattended when it is plugged in.
- Close supervision is necessary when this appliance is used by, on, or near children or in individuals with certain disabilities or special needs.
- Use this appliance only for its intended use as described in this manual.

2

**PERFORMANCE**

This Newest generation straightener built in nutrition system,with scientific design construction, while straightening hair, opening the scale of the hair, instantly the nutrition enters into hair.

During hair cooling time, the nutrition will be locked into hair, penetrates deep into the hair to replenish essential moisture

The NutriHeat Silk Protein Capsule contain silk proteins to restructure and repair dry damaged hair, for strengthened hair that really shines, the protein is activated by the heat of the straightener to give perfect, long-lasting results and super shine.

A built-in nutrition system works with heat to control the release time of the cosmetic formula, evenly release active proteins, panthenol and thermo-sleek complex during the straightening process.

MIRROR Titanium offer supper smooth glide, effortless straightening experience, no need to put strength to pull hair

Heating plates wrap around edge allow to get closer to the roots on short hair or bangs without fear of burning your scalp

3 heat settings from 340°F-380°F-410°F to adapt to all hair types

**INSTRUCTIONS FOR USE**

→ Ensure hair is dry and combed through.

- 1: PRESS 'Power Switch' 3 SECONDS to turn on appliance.  
On/Off and temperature control (same button)

3

**INSTRUCTIONS FOR USE**

- 2: Temperature comes 3 temperature setting, 340°F-380°F-410°F

- 3: Press On/Off button to turn on appliance, default temperature 340°F  
Press On/off button again, set desired temperature to 380°F  
Press On/Off button again, set desired temperature to 410°F  
When temperature indicate light is flashing, heating plate is heating up, once indicate light stop flashing, heating plate reach desired temperature.

- 4: Press the NutriHeat Silk Proteins Infusion On/Off button to turn on Silk Protein Shine Infusion Therapy function  
Press the NutriHeat Silk Proteins Infusion On/Off button again to turn off Silk Protein Shine Infusion Therapy function

- 5: 1 hour auto shut off

- Separate a section of hair.
- Place the flat iron close to the roots of selected hair, hold the hair end firmly and brush down the length of the hair, from root to tip.
- Repeat as necessary.
- Allow the hair to cool down before other styling application.
- After use, press the button 'Power Switch', please press for 3 seconds and unplug the appliance.
- Please wait until cooling down to pack up the flat iron

4

**SAFETY CAUTIONS**

**AUTO SHUT OFF**

This appliance has an automatic shut off feature for added safety. If the appliance is switched on for more than 60 minutes continuously, then it will automatically switch off. If you wish to continue using the appliance after this time, simply press the 'Power Switch' button to turn the power on.

**CLEANING & STORAGE**

Ensure the appliance is completely cool before placing inside the storage pouch

Always place the appliance on the heat resistant mat while styling hair to protect work surfaces

Use small fabric or cleansing to clean the flat iron

**SAFETY CAUTIONS**

This appliance should only be used as described within this instruction manual. Please retain for reference.

**WARNING!** Polythene bags over a product may be dangerous. To avoid danger of suffocation, keep this wrapper away from babies and children. These bags are not toys.

**WARNING!** Do not use this appliance near water contained in basins, bathtubs or other vessels.

Do not immerse the appliance in water or other liquids.

Do not use the appliance in the bathroom.



5