



We believe that every technician has the hands of an artist to bring us beauty and confidence. The **Artist hand** brand will provide you with One-stop service and experience to assist you to create a better life by opening your own store!

Artist hand is a rapidly growing e-commerce platform which provides high quality specialists products for the beauty, nails, hair, barber, massage and spa stores.

We are committed to providing perfect quality, reasonable price and excellent service for every beauty, nail, salon, barber, massage & spa industry. and becoming a favorite amongst professionals. There is a wide selection of styles from vintage to modern and more functional designs.

Meanwhile, customized packages can include one-stop packaged furniture and equipment for a range of high-quality styling equipment that complements your store.

 ▪ **Amazon** : <https://www.amazon.com/artisthand>

 ▪ **Website** : www.artisthandbeauty.com

 ▪ **Customer service Mailbox** : info@artisthandbeauty.com

 ▪ **Facebook** : Artisthand

 ▪ **Instagram** : artisthandbeauty

 ▪ **TikTok** : artisthandshop

 ▪ **YouTube** : Artisthand

 ▪ **Installation video in youtube.com/c/Artisthand** :
Search No.: U3070107100




Amazon Shop



Artisthand Website



Artist hand[®]
SALON & SPA EQUIPMENT



SPA Bed

Instruction Manual

COLOR: Black U3070107100

Power: 1000W	Rated Voltage: AC110V	Rated Frequency: 50/60Hz 2A
------------------------	---------------------------------	---------------------------------------

1 Tools required


A Phillip head screwdriver & M4 & M6 Allen key or Power tools is required for the assembly of this product.(not included)

2 1 person is needed

3 Take minutes

3 mins

1.1 Feature and Specification




Main Parts


Parts Code	Image	Parts Name	Qty(Pcs)
A		Bed	1
B		C-Shaped Pillow Bracket	1
C		C-Shaped Pillow	1
D		Bolster	1
E		Lumbar Pillow	1
F		Standnails	6

1.2 Installation Diagram



Step 1





Step 2



Step 3





Step 4










1.3 Operation Guide

Step 5




Step 6





1. Operation Guide for Water Cycle



Basic Information:

Compatible Current: AC110V/50HZ and 60HZ (universal)

1.1 Voltage Range: AC110v

1.2 Power: 1000W(110V/60HZ)

1.3 Operating Temperature: -10 to 90°C

1.4 Humidity: Over 95% (at 25°C)

1.5 Storage Temperature: -40 to 80°C

2. How to Use (Water Cycle)

2.1 Overview of Functions: When you power on the machine, all the indicators will light up for 1 second, then the machine will go into standby mode. After starting the machine, the right side of the display shows the heating status or the water temperature when not heating. When adjusting the temperature, it shows the target temperature. The left side of the display shows the water outlet temperature, timer, and speed settings.

2.2 Button Guide: (POWER) Turn the machine on or off. (SPA SWITCH) Start or stop the head therapy. (TEMP+) (TEMP-) Adjust the water temperature between 30-50°C. (-TIME+) (-TIME-) Set the timer between 10-90 minutes, in minute increments. (SPA MODE) Adjust the water pump speed between 1 and 2 levels. (LIGHT ON) Turn the light therapy on or off.

3. Important Tips for Water Cycle

3.1 First-Time Use: Before using the machine for the first time, do not power it on. First, fill the basin with water by pressing the nozzle against the filter inlet. Once water starts flowing from the outlet ring, you can power on the machine. If there's air in the pipes, the machine won't work properly.

3.2 Do Not Operate Without Water: Always make sure the basin is filled with water before turning on the machine. The water should cover the filter inlet by at least 3CM, or the machine may malfunction.

3.3 Setting Temperature and Timer: A typical temperature setting is around 40°C. Avoid setting it too high. A usual time setting is 30 minutes.

3.4 Draining After Use: After using the machine, turn it off before draining the water. Do not remove the filter screen during this process. After all the water has drained, remove and clean the filter.

4. Maintenance for Water Cycle

4.1 Keep the Machine Dry: Protect the machine from water and avoid using it in very humid environments.

4.2 Clean the Filters Regularly: The machine has two filters to prevent long hair and other debris from clogging it. After each use, clean the first filter in the basin. Clean the second filter under the basin every 2-3 days. After cleaning, reinstall the filter and repeat the first-time use procedure.


5. Common Error codes for Water Cycle

E1: Electrical Leakage- Solution: Return the machine for repair.


E2: Temperature Sensor Issue- Solution: Replace the temperature sensor.

E4: Overheating or Dry Running - Solution: Turn off the machine, repeat the first-time use procedure, and the machine should work again.

6. Operation Guide for Shampoo Basin



7. Operation Guide for Footbath




8. Maintenance



Shampoo Basin Inspection



Foot Basin Inspection



9. Trouble Shooting

1. No Water from the Outlet Ring:

Step 1: Check if the filters are clogged and clean them.

Step 2: fill the basin with water using the nozzle as described in the first-time use instructions. If water flows, check if the water pump plug is loose or if debris is blocking the pump. Clean and reassemble the pump if needed. If no water flows, there may be a blockage or a kink in the hose. Check and replace the hose if necessary.

2. Loud Noise: Check if the pump is touching any hard objects or connected with metal pipes. If not, the pump might be worn out or damaged from running without water. Replace the pump if needed.

10. Product Size



Backrest Up/Down

11. Customer Service

Any question or suggestion please feel free to contact our Customer Service Team

E-mail: info@artisthandbeauty.com

12. WARNING:

ANY PACKING BAGS OF THIS PRODUCT ARE NOT A TOY.
TO AVOID DANGER OF SUFFOCATION, KEEP AWAY FROM BABIES AND CHILDREN. DO NOT
USE IN CRIBS, BEDS.