



Product Structure (inch)



Installation


It's very easy to install, as shown below:



Usage

There are two ways to control : Foot switch control/Remote control

Foot switch ON/ OFF



Remote Control



- ①H Set a 1h timer (Lamp Light get several flickers mean 1h timer is successful set)
- ⏻ Short press to turn on/off light.
- ☀+ Short/Long press to enhance the CCT (3000K to 6000K) as you like.
- ☀- Short/Long press to lower the CCT (6000K to 3000K) as you like.
- ☀ Short press to be the max brightness and CCT immediately.
- ☀+ Short/Long press to enhance the brightness as you like.
- ☀- Short/Long press to lower the brightness as you like.
- Ⓚ Short press to Adjust Color Temperature 4 Levels.
- 📖 Short press to enter reading mode.
- 🕯 Short press to enter breastfeed mode.
- 🌙 Short press to enter night mode.
- 💻 Short press to enter work mode.

1、 When can you use the remote control?

A 9w 1000Lumens intelligent bulb is included in the package. You may use regular bulb to replace the intelligent bulb if you prefer that. Please note that regular bulb cannot match the remote control. Need to repair the remote control and bulb if you replace one of them. Please check the repair method below.

Foot switch is the prerequisite for remote control. Make sure you have turned on the lamp with the foot switch when you using the remote for turning on/off, changing the CCT, modes and timer. Remote control cannot be used if foot switch is turning off status.

2、 How to repair the remote control and the bulb if the remote is not working?

Long press the '⏻' button on the remote control and turn on the lighting by foot switch at the same time. When you see the bulb flashes, it means the matching process is completed and you can use the remote now.