



Product Manual

Please read the manual carefully before using the lamp.

Thank you for purchasing LED lamp. It is designed to maximize the quality and comfort of your work.

The manufacturer shall not be liable for any trauma of injuries caused to persons or damage to property caused by failing to follow instructions in this manual.



- ① Lamp body 1pc
- ② Iron base 2pcs
- ③ Power supply 1pc
- ④ Screwdriver 1pc
- ⑤ Fixing screw 4pcs

Assembling:

1. Carefully open the box
2. Plug into 100-240V power outlet
3. Assemble according to instructions

Assembly instruction:

1. Use a screwdriver to fix the iron base to the lamp body
2. Cover the iron base with rubber pads
3. Connect the power supply
4. Press on/off sensor button shortly to switch on the lamp

To use the lamp:

1. Install the lamp to the working desk and connect with the power supply
2. Press on ON/OFF button shortly to switch on the lamp. Use same short press to switch change the light color (2700K-4000K-6500K) or OFF the lamp.
3. Pressing the ON/OFF button longer will result in regulation of the lamp brightness (dimming function). Press and release the ON/OFF button when you are satisfied with the lamp brightness.
4. Lamp memorizes the brightness setting and it is used next.