











INSTALLATION INSTRUCTIONS

ASSEMBLY DIAGRAM




PARTS LIST

PARTS LIST			HARDWARE LIST		
No.	Description	QTY	No.	Description	QTY
1		1	20	 Three-in-one Connector	44
2		1	21	 Screws	24
3		1	22	 Handle	2
4		1	23	 Slider	2
5		1	24	 Hanger	2
6		1		 ST4×30 Screws	4
7		2		 ST4×50 Screws	6
8		2	25	 Bracket	2
9		1	26	 Screws For Fix On The Wall	2
10		1			
11		1			
12		1			
13		1			
14		1			
15		1			
16		1			
17		1			
18		1			
19					

CAUTION: Please confirm the parts list before installation


YOU MAY NEED (NOT SUPPLIED)












INSTALLATIONS

STEP 1

HARDWARE LIST





20		44 PCS	
----	---	--------	--



● Insert the Cam Screw into the shelves above.




STEP 2

HARDWARE LIST		
21		8 PCS
23		2 PCS
24		2 PCS
24	 (ST4x30)	4 PCS



STEP 3

HARDWARE LIST		
20		16 PCS







STEP 4

HARDWARE LIST

25 2 PCS

21 16 PCS





STEP 5

HARDWARE LIST


20 16 PCS

22 2 PCS


22 1 PCS




STEP 6








HARDWARE LIST		
20		8 PCS
22		2 PCS
22		1 PCS




STEP 7



HARDWARE LIST		
24		2 PCS
24		6 PCS
24		6 PCS
26		2 PCS






STEP 8



STEP 9

HARDWARE LIST		
26		2PCS
		



● Through the screw to adjust position of the hange




a up and down

b front and back





STEP 10

HARDWARE LIST

② 8 4 PCS



STEP 11



● Assembled drawers are loaded onto cabinets.

CARE AND CLEANING

1. Many cleansers contain abrasive and chemical substance which is not suitable for cleaning stainless steel, enamel, plating or plastic products. You may use mild cleansers or soaps to clean the surfaces. Wipe any splashes of cleaner solutions from the surface with a clean soft cloth.
2. Maintain ventilation in the bathroom and separate the dry area from the damp one if conditions permit. Try to open the door and windows of the bathroom to maintain adequate ventilation.
3. This cabinet is built to withstand normal bathroom humidity. For best results, keep this vanity dry and take necessary steps to minimize bathroom humidity by opening windows and doors and using the exhaust fan (if available).
4. To maintain the cabinet door, clean and wipe the door regularly with a soft cloth. Wipe condensation with a dry, soft cloth. Keep away from high temperatures.
5. Please do not sit, lean or step on the basin cabinet.