












Bench




1		10 pcs	2		6 pcs	3		10 pcs	4		12 pcs
5		6 pcs	6		6 pcs	7		1 pc	8		38 pcs

CAM LOCK SYSTEM



(1)




(2)



IMPORTANT NOTE—CAM LOCK ADJUSTMENT




If Cam Lock
is too loose,
Please adjust Metal
Dowel to turn right
as drawing.




If Cam Lock
is too tight,
Please adjust Metal
Dowel to turn left
as drawing.


Step 1




Step 2




Step 3



Step 4




Step 5




Step 6

X 4




Step 7



Slide out the side panel drawer slides for proper insertion of the drawers.

Step 8



Line up the drawer slides on the drawers on both sides so that they enter evenly into the extended receiving side panel drawer slides as shown then gently push in the drawer until the drawer is secure and slides in and out smoothly.