

Brightech®

LightView Pro Magnifying Glass With Color Changing Light

Assembly & Free Extended Warranty Instructions

1. Clamp the bracket to the edge of any horizontal surface.
2. Insert the stem at the bottom of the arm into the hole of the bracket.
3. Plug the magnifier lamp into an outlet.

Brighten warm white LEDs
Dim warm white LEDs
Dim cool white LEDs
Brighten cool white LEDs



For safe use:

- 1) Use indoors only. Avoid direct sunlight to prevent fires!
- 2) Environment Temperature 23° F - 104° F.
- 3) Humidity: Below 95%.

Caution: The glass lens is held in place by a ring. The ring unscrews so you can remove the lens for cleaning. Before first use and after any time you remove the glass, ensure the ring is screwed back on all the way.

Free: Extend Your Warranty For Two More Years

Extend your warranty from 3 years to 5 by registering your purchase. Just fill in the brief product registration form at brightechshop.com/pages/extended-warranty/

If you have any questions or issues, please contact us at wecare@brightechshop.com