

Electric Vibro Separator TB-830



MANUAL

Please keep this manual and read before use

Dear customer:

Thank you for choosing our electric vibro separator. Welcome to contact us if you have any suggestions or questions. We will serve you in time.

Warning :Please read this manual carefully, and place the machine properly before run the machine, which avoid accident happen.

Attention: Because of the continuous improvement of the products, the machine you purchased may differ from the picture shown in this manual, please refer to the actual items.

SPECIFICATION

Model	TB-830
Voltage	110V
Power	50W
Vibration frequency	1350N/min
Screen Diameter	300mm
Dimension	300*320*390mm
Weight	10kg

OPERATING INSTRUCTIONS

Attention

Please use under the following conditions:

1. The equipment shall not be exposed to extremely humid environment, should be with good illumination and away from combustible gas and liquid.
2. When using the equipment, it should be placed in a flat and solid place.
3. Before using the equipment, check whether there are slightly worn parts carefully, observe whether the moving parts are faulty, and replace them to ensure safe and normal operation.
4. The equipment must be connected to the earth.
5. Check whether the input power supply is qualified every time it is used.
6. When cleaning, the power must be cut off and the plug must be pulled out.
7. Always keep fire extinguishers in the work area.
8. Keep the machine clean everyday.