



ASSEMBLY INSTRUCTION





















TIPS










1. Please read the instructions fully before assembly. These instructions include important information which could ensure correct assembly. We have been working on providing high quality products for you. However, in the rare instance that your product is defective, missing parts or there are some issues, please don't hesitate to contact our customer service to submit parts requirements, assembly suggestion, or warranty claims, and we will give the best solution as soon as possible. If necessary, we need you to provide some more clear pictures of the issue.
2. Insert the screws in holes and tighten the screws, but not too tight, 70%~80% is ok, finally tighten all the screws. If some issues happened that some screws can not target to the hole or some parts are difficult to install, please adjust the tightness of the screws.
3. 2 people are recommended to finish.





Part list


1  x 1	2  x 1	3  x 1		
4  x 1	5  x 2	6  x 1		
7  x 24	8  x 1	9  x 1	10  x 2	
11  x 1	12  x 2	13  x 2	14  x 2	15  x 1
16 	17  x 1	18  x 2	19  x 2	
20  x 1		21  x 2		

Part list


22  x 2	23  x 4	24  x 2	25  x 1	26  x 1	
27  x 1	28  x 2	29  x 1	 Q x 12	 S x 24	

Hardware list

 A M8x14 x 44	 B M8x25 x 4	 C M8x37 x 18	 D M8x30 x 4	 E M8 x 4	 F M6x60 x 2	 G M6x70 x 2	 H M6x14 x 2	 I M6x20 x 2	 J x 1	 K M8 x 1	 N M6 x 1
---	---	--	---	--	---	---	---	--	--	--	--



This product is not suitable for mattress recessed type.



This product is suitable for placing mattresses on the top.

IMPORTANT NOTICE OTTOMAN OPERATING INSTRUCTIONS

Once your bed frame is completely assembled, the slat unit will not operate correctly unless a mattress is placed on the slat frame. Position the mattress on the slat frame whilst it is in the closed position.

PLEASE NOTE - It takes a lot of force to make the initial movement of the ottoman. This is a design feature of the product so that it does not fall shut-the nearer to being closed the ottoman is, the easier it is to move. When the ottoman is almost shut, it will close completely under its own weight.

When lowering the slat unit for the first time, take care to make sure it does not rub unevenly on the inside face of the side rails. If it does, the bed has been assembled slightly out of square. This can be rectified by moving the foot end of the bed slightly to the left or right whilst leaving the headend stationary.



PISTONS

The pistons used in the construction of this product are extremely strong and cannot be operated by hand when taken off the ottoman. All pistons are tested for correct pressure and operation before being attached to the slat unit.

Initially it might appear that the pistons are very stiff when opening and closing the ottoman.


THIS IS PERFECTLY NORMAL

When fully assembled and the mattress is in position, please raise and lower the ottoman 4/5 times to ensure the gas piston are fully lubricated.




Step 1:

- F 0 x 2
- G 0 x 2
- N x1
- A x4
- K x1






Step 2:

- G 0 x 2
- K x1



Step 3:




Step 4:

UK:Part 5 should be 185mm from the edge of the panel

DE:Teil 5 sollte 185 mm von der Plattenkante entfernt sein

FR:La partie 5 doit être à 185mm du bord de la planche




Step 5:



UK:Part 5 should be 55mm from the edge of the panel


DE:Teil 5 sollte 185 mm von der Plattenkante entfernt sein

FR:La partie 5 doit etre à 55mm du le bord de la plaque doit être retiré






Step 6:

- A  x4
- B  x4
- K  x1






Step 7:



- C  x8
- K  x1




Step 8:




Step 9:







Step 10:





Step 11:








Step 12:





NOTE: Do Not Overtighten
HINWEIS: Ziehen Sie die
Schrauben nicht so fest an
Attention : Ne pas trop
serrer les vis





Step 13:



Step 14:






Step 15:



UK: One side of the light bar is the luminous surface, and the other side is the velcro tape.
 DE: Die Rückseite der Lichtstreifen ist mit einem Klettband versehen, um die Montage zu erleichtern.
 FR: La bande LED est équipée de velcro autocollant à l'arrière




Step 16:



UK:Please string the thread to the elastic band.

DE:(Befestigen Sie das Kabel an dem Gummiband auf dem Bettrahmen)

FR:(Veuillez faire passer le câble LED à travers la bande élastique)




UK:There is a two-dimensional code at the position of the power line.Scanning can download the APP for the control light

DE:Scannen Sie den QR-Code auf dem Adapter und laden Sie die APP zum Einstellen der Beleuchtung herunter.

FR:Veuillez scanner le code QR sur le cordon d'alimentation et télécharger l'APP pour contrôler le ruban LED

Step 17:



LED light



If you can't let the lights work successfully, please check the following:

1. Please check the direction of the connect, try it in the opposite direction, according to the following picture.
2. Please check the remote control, it need you to tear down the plastic septum before use it.
3. If one of the colors is not bright, please check whether the four wires in the plug are skewed, and move the main line to make the four wires flush.

(LED-Licht)

(Wenn Sie die Lampe nicht erfolgreich funktionieren lassen, überprüfen Sie bitte Folgendes:

1. Bitte überprüfen Sie die Verbindungsrichtung und versuchen Sie in der entgegengesetzten Richtung gemäß der Abbildung unten.
2. Bitte überprüfen Sie die Fernbedienung und entfernen Sie die Kunststoffmembran vor Gebrauch.
3. Wenn eine der Farben nicht hell ist, überprüfen Sie bitte, ob die vier Drähte im Stecker schief sind, und bewegen Sie die Hauptleitung, um die vier Drähte bündig zu machen.)



UK: There is a two-dimensional code at the position of the power line. Scanning can download the APP for the control light
DE: Scannen Sie den QR-Code auf dem Adapter und laden Sie die APP zum Einstellen der Beleuchtung herunter.
FR: Veuillez scanner le code QR sur le cordon d'alimentation et télécharger l'APP pour contrôler le ruban LED

1. Please check the direction of the arrow
 2. Please pull the plastic block out of the remote control
 3. Please check whether the four wires of the plug are neat
- (1. Bitte überprüfen Sie die Richtung des Pfeils
2. Ziehen Sie bitte den Kunststoffblock von der Fernbedienung
3. Bitte überprüfen Sie, ob die vier Drähte des Steckers bündig sind)

Operation Instructions of Controller (Betriebsanleitung des Reglers)

I. Specifications: (Spezifikationen)

Working temperature: -20-60 °C
(Arbeitstemperatur: -20-60 °C)

Product size: L62xW35xH23mm
(Produktgröße: L62xW35xH23mm)

Net weight: 42g
(Nettogewicht: 42g)

Output: Three CMOS drain- open output
(Ausgabe: Drei CMOS Drain- Open Ausgang)

Max load current: 2 A each color
(Maximaler Ladestrom: 2 A pro Farbe)

Supply voltage: DC12V
(Versorgungsspannung: DC12V)

Package size: L95xW68xH45mm
(Packungsgröße: L95xW68xH45mm)

Gross weight: 57g
(Bruttogewicht: 57g)

Connecting Mode: Common anode
(Verbindungsmodus: Gemeinsame Anode)

II. Control Method:


Adopt RF remoter to control the led controller, which has 24 buttons, the function of each button as the table below:

(Kontrollmethode:

Nehmen Sie RF-Fernbedienung an, um den geführten Controller zu steuern, der 24-Tasten hat, die Funktion jeder Taste wie die Tabelle unten:)

Brightness +(Speed up) (Helligkeit +(Beschleunigung))	Brightness - (Speed down) (Helligkeit - (Geschwindigkeit runter))	Off (Aus)	On (Ein)
Static red (Statisches Rot)	Static green (Statisch grün)	Static blue (Statisch blau)	Static white (Statisch weiß)
Static orange (Statisch orange)	Static pea green (Statisches Erbsengrün)	Static dark blue (Statisch dunkelblau)	7 color jumpy change (7 Farbwechsel)
Static dark yellow (Statisch dunkelgelb)	Static cyan (Statisches Cyan)	Static brown (Statisch braun)	All fade out&fade in (All fade out&fade in)
Static yellow (Statisch gelb)	Static light blue (Statisch hellblau)	Static pink (Statisch rosa)	7 color fade change (7 Farbwechsel)
Static straw yellow (Statisches Strohgelb)	Static sky blue (Statisches Himmelblau)	Static purple (Statisches Lila)	3 base color jumpy (3 Grundfarbe nervös)

III. Panel specification and connecting drawing as follows: (Plattenspezifikation und Anschlusszeichnung wie folgt)



IV. Warning:

1. Supply voltage of this product is USB5V never connect to DC24V or AC220V.
2. Never connect two wires directly in case of short circuit.
3. Lead wire should be connected correctly according to colors that connecting diagram offers.
4. Warranty of this product is one year, in this period we guarantee replacement or repairing with no charge, but exclude the artificial situation of damaged or overload working.

(Warnung:

1. Supply Spannung dieses Produkts ist USB5V niemals mit DC24V oder AC220V verbinden.
2. Nie verbinden Sie zwei Drähte direkt im Falle eines Kurzschlusses.
3. Lead Draht sollte entsprechend den Farben richtig angeschlossen werden, die Verbindungsdiagramm anbietet.
4. Warranty dieses Produkts beträgt ein Jahr, in diesem Zeitraum garantieren wir Ersatz oder Reparatur ohne Gebühr, schließen aber die künstliche Situation der beschädigten oder überlasteten Arbeit aus.)

! WARNING

THIS PRODUCT CONTAINS A BUTTON BATTERY

If swallowed, a lithium button battery can cause severe or fatal injuries within 2 hours.

Keep batteries out of reach of children.

If you think batteries may have been swallowed or placed inside any part of the body, seek immediate medical attention.

! WARNUNG

Dieses Produkt enthält eine Knopf-Batterie

Beim Verschlucken kann eine Lithium-Knopf-Batterie innerhalb von zwei Stunden schwere oder tödliche Verletzungen verursachen.

Bewahren Sie Batterien außerhalb der Reichweite von Kindern auf.

Wenn Sie glauben, dass Batterien verschluckt oder in einen Teil des Körpers gelegt wurden, suchen Sie sofort einen Arzt auf.