

WL7090-1CH
OPERATIONS MANUAL

Instruction

WL7090-1CH Installation Procedure:

- Step 1: Unscrew screw E from the lamp body and remove the hanging plate C;
 - Step 2: Install the hanging plate C lock on the junction box A with screw D;
 - Step 3: Use terminal B The ground line and the input line are connected respectively;
 - Step 4: Lock the lamp body F on the hanging plate C with screw E;
- Installation completed.

The light source can be switched between 3000K/4000K/5000K by dialing.

