


Assembly Instructions for item : Stiletto Series - 24"
Dimmable LED Sconce/Bath Bar 32" Dimmable LED
Sconce/Bath Bar

Important: Always disconnect the power before installing or replacing bulbs and before cleaning or other maintenance.

This light should be installed by a licensed electrician

LAMP INSTALLATION AND ASSEMBLY

1. Shut off power to the outlet box. (fig. A)
2. Loosen the hex nuts on back plate, grasp the spacer, and slide the fixture to desired position, feeding the fixture cord through the back plate as needed. Tighten the hex nut to set.
3. Make appropriate electrical connections using wire nuts:
 - a. Connect the LED driver's live wire (brown/black) to the live outlet box wire.
 - b. Connect the LED driver's neutral wire (blue/white) to the neutral outlet box wire.
 - c. Connect fixture's ground wire (green or uncoated) to the ground outlet box wire. If no ground is present in outlet box, connect fixture's ground wire to the mounting plate using the green screw (included).
 - d. Carefully place connections and LED driver in outlet box.
4. Attach the mounting plate to the outlet box, secure with outlet box screws.
5. Connect the male quick connector from the fixture to the female quick connector from the driver. The quick connector is polarized and will only fit together the correct way. Do not force the connector together backwards or damage will occur.
6. Store any excess fixture cord in the back plate.
7. Attach the back plate to the mounting plate, secure with mounting screws.
8. Restore power to the fixture. **CAUTION:** The fixture must be connected to the driver before restoring the power, or damage will occur.



NOTE: This fixture is dimmable with Electronic Low Voltage (Trailing-Edge) and Incandescent (Leading-Edge) type dimmers. For best performance, we recommend using an Electronic Low Voltage dimmer.

CARE INSTRUCTIONS

Dusting — Use a clean, dry cloth.

Cleaning — To protect the finish, avoid any harsh abrasives or chemicals.

Fingerprints on the acrylic can be removed with rubbing alcohol.

