robern

Robern 701 N. Wilson Ave. Bristol, PA 19007 800.877.2376

SS512 SAFETY LOCK BOX INSTRUCTIONS – MODEL SLB

2 (2 per side)

Fig. 2

(B)

œ

a

Fig. 4

æ

res)

۲

æ

BACK OF

CABINET

[A]

[B]

ر**ل**


of the cabinet as shown.

General Notes


1. Check to be sure you have the correct kit for your cabinet. Check the box label as well as the silver label on the inside of the lock box door. The box label describes the cabinet model the lock box designed to fit.


NOTE: This product is only a deterrent. It is not a substitute for proper adult supervision.

2. If you experience any problems with your Lock box, please contact your dealer or Robern directly by calling our toll free customer service line between 8 a.m. and 4 p.m. E.S.T. (1.800.877.2376) Have the available serial number and model number. Robern • 701 N Wilson Ave • Bristol, PA 19007 800 877 2376 • FAX 215 826 9633



A. The lock box uses 3 rows of hinge holes as shown.





Install the hinge pins first into the lock box, then the shelf support.

A. Slide the hinge pins in all the way until they are flush with the edge of the lock box door.

B. Slide the pins into the shelf supports using a thin object such as a screwdriver blade until they "click" into position.

Note: To remove pins, use a pointed tool in the groove, push the pin towards the center of the door.


Install the 2 shelf locks on the top shelf only before installing

[B]

A. Slide the locks on the shelf

B. Once the top shelf is installed, the shelf lock will slide into the shelf support.

Push in firmly to seat the shelf lock



Install the lock box shelves. 6

The shelves lock the system in place and set the lock cam.

A. Install the shelves as shown.


o

BACK OF

CABINET

Ô

- B. Slide the shelf locks into the shelf supports as shown in #5
- C. Test the lock. The key will only remove in the locked position.



SS512 Lock Box Instructions Rev 2 9/02