















## Parts & Hardware Included:

Picture	Description	Qty	Check list
	Crown beauty	1	A
	Ø50*20 light holder	1	B
	M10*5 hexagon female	2	C
	Ø220*150 lampshade	1	D
	250mm long grape skewer	22	E
	180*60 bracket	1	F
	Ø30*50 light cup With E12 lamp holder	1	G
	Ø19*250 inner dental tube	1	H
	Ø80 round piece	1	I
	Desk lamp switch cable	1	J
	Ø150*25 lamp holders	1	K

Lighting structure explosion diagram



## Installation procedure

- Carefully disassemble and identify each part to ensure that you are ready  
To install everything, place each part on a clean flat surface, such as a table  
Son or floor.
- Cut off the main power supply to the fuse box or circuit breaker in the house or building.
- Installation steps (as prompted on the left)  
Step 1: (Install and connect H-I-J-K-L) fittings.  
Step 2: Follow the instructions on the left to install.  
Step 3: Put the crystal lamp shade into the dental tube H and lock it tightly with the hexagonal female C.  
Step 4: Cover the B lamp holder and lock it with A.
- Install the light source, connect the power supply, press the switch on the switch line to test the light. Save these instructions for future use. If the lights do not work, you can contact our customer service team to resolve the issue
- maintenance methods  
Clean the water with a soft dry cloth or an electrostatic duster  
Avoid using harsh chemicals and abrasives to clean the fixture and smooth the surface  
Deal.
- Use safety precautions  
Your light is in the water, which will damage the wiring.
- after-sales questions can be contacted on the platform order page  
We hope you enjoy your new lighting as much as if your project achieved  
Or exceed your expectations, we will be honored if you write us one  
A review that shares your experience can help others and other customers get to know you  
The idea. To your support like this we make money and we really appreciate it.
- The finger mold and sweat left on the metal and crystal surface of the lamp body after installation  
The trace can be cleaned with a soft dry cloth or an electrostatic duster.