


# Storage Cabinet



Made in China

## WARNING

Serious or fatal injury may occur from unexpected assembly or use.

1. During the assembly process, keep all parts away from babies or children.
2. Always securely fix this product to the wall. Make sure the wall area to be drilled is free from hidden electrical wires, water and gas pipes.
3. Use of tip-over restraints may only reduce, but not eliminate the risk of tip-over.
4. Unless specially designed to accommodate, do not set heavy objects on top of this product.
5. Place the heaviest items on the lowest shelf.
6. Never allow children to climb or bang on drawers, doors or shelves.


## WARNING







**Children have died from furniture tipover. To reduce the risk of furniture tipover:**

- **ALWAYS** install tipover restraint provided.
- **NEVER** put a TV on this product.
- **NEVER** allow children to stand, climb or hang on drawers, doors, or shelves.
- **NEVER** open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

# Parts List(EN)/Teile Liste(DE)



















# Parts List (EN) / Teile Liste (DE)







<p>① one side</p> <p>the other side</p> <p>1050*400*15mm 1PC</p>	<p>②</p> <p>915*400*15mm 1PC</p>
<p>③</p> <p>915*400*15mm 1PC</p>	<p>④ one side the other side</p> <p>800*380*15mm 1PC</p>
<p>⑤ one side the other side</p> <p>1080*400*15mm 1PC</p>	<p>⑥</p> <p>685*250*12mm 3PCS</p>
<p>⑦</p> <p>342*250*12mm 2PCS</p>	<p>⑧</p> <p>1050*120*15mm 1PC</p>
<p>⑨</p> <p>1056*349*3mm 1PC</p>	<p>⑩</p> <p>1056*349*3mm 1PC</p>






















# Parts List (EN) / Teile Liste (DE)



<p>⑪</p>  <p>134mm</p> <p>5PCS</p>	<p>⑫</p>  <p>1050*100*15mm</p> <p>1PC</p>	
<p>⑬</p>  <p>795*341*15mm</p> <p>1PC</p>	<p>⑭</p>  <p>1PC</p>	
<p>⑮</p>  <p>654*341*15mm</p> <p>1PC</p>	<p>⑯</p>  <p>654*341*15mm</p> <p>1PC</p>	<p>⑰</p>  <p>688*70*15mm</p> <p>1PC</p>
<p>⑱</p>  <p>683*120*15mm</p> <p>1PC</p>	<p>⑲</p>  <p>639*80*12mm</p> <p>1PC</p>	
<p>⑳</p>  <p>300*80*12mm</p> <p>1PC</p>	<p>㉑</p>  <p>300*80*12mm</p> <p>1PC</p>	<p>㉒</p>  <p>647*296*3mm</p> <p>1PC</p>




# Hardware List (EN) / Teile Liste (DE)






<b>A</b>  $\varnothing 15 \times 9 \text{mm}$ <b>28PCS</b>	<b>B</b>  $\varnothing 6 \times 35 \text{mm}$ <b>28PCS</b>	<b>C</b>  $\varnothing 8 \times 30 \text{mm}$ <b>10PCS</b>	<b>D</b>  M4*20mm <b>5PCS</b>	
<b>E</b>  $\varnothing 28 \text{mm}$ <b>5PCS</b>	<b>F</b>  $\varnothing 3 \times 15 \text{mm}$ <b>48PCS</b>	<b>G</b>  40*15*12mm <b>3PCS</b>	<b>H</b>  $\varnothing 6 \times 17 \text{mm}$ <b>20PCS</b>	
<b>I</b>  16*16*11mm <b>10PCS</b>	<b>J</b>  $\varnothing 4 \times 14 \text{mm}$ <b>24PCS</b>	<b>K</b>  40*18*18mm <b>6PCS</b>	<b>L</b>  70*32*13mm <b>2PCS</b>	
<b>M</b>  $\varnothing 4 \times 40 \text{mm}$ <b>2PCS</b>	<b>N</b>  $\varnothing 8 \times 35 \text{mm}$ <b>2PCS</b>	<b>O</b>  $\varnothing 20 \text{mm}$ <b>28PCS</b>	<b>Q</b>  12" <b>1PC</b>	
<b>P</b>  $\varnothing 4 \times 25 \text{mm}$ <b>6PCS</b>	<b>R</b>  $\varnothing 3 \times 12 \text{mm}$ <b>12PCS</b>	<b>S</b>  70*67*12mm <b>4PCS</b>	<b>T</b>  50*50*8mm <b>1PC</b>	<b>U</b>  <b>3PCS</b>



# Assembly (EN) / Montageschritte (DE)

## CAM BOLT INSTALLATION AS BELOW:






## STEP 1






	C * 4PCS
	B * 3PCS


# Assembly (EN) / Montageschritte (DE)


## STEP 2



	B * 2PCS
	G * 1PC
	F * 2PCS


## STEP 3




	A * 3PCS
---	----------

# Assembly (EN) / Montageschritte (DE)



## STEP 4



## STEP 5




Lock the slides on to the plate according to the holes shown in the illustration.

	CR * 1PC
	R * 3PCS


# Assembly (EN) /Montageschritte (DE)

## STEP 6



	G * 2PCS
	F * 4PCS
	C * 4PCS
	B * 1PC

## STEP 7




Lock the slides on to the plate according to the holes shown in the illustration.


	CL * 1PC
	R * 3PCS

# Assembly (EN) / Montageschritte (DE)

## STEP 8




## STEP 9



A \* 3PCS


# Assembly (EN) / Montageschritte (DE)

## STEP 10




A \* 5PCS

## STEP 11




Thin back board needs to be inside the slot, otherwise blocks the opposite plate montage.

STEP 12



A \* 4PCS


STEP 13









Thin back board needs to be inside the slot, otherwise blocks the opposite plate montage.

# Assembly (EN) / Montageschritte (DE)


## STEP 14



	B * 6PCS		T * 1PC
	S * 4PCS		J * 24PCS




## STEP 15




Assembly (EN) / Montageschritte (DE)

STEP 16



A \* 6PCS


STEP 17



A \* 2PCS


# Assembly (EN) / Montageschritte (DE)

## STEP 18



H \* 20PCS

## STEP 19




F \* 2PCS



L \* 2PCS





# Assembly (EN) /Montageschritte (DE)

## STEP 20



P \* 6PCS


## STEP 21



B \* 5PCS


# Assembly (EN) /Montageschritte (DE)

## STEP 22



A \* 5PCS

## STEP 23



DL \* 1PC



DR \* 1PC




R \* 6PCS

Lock the slides on to the plate according to the holes shown in the illustration.

# Assembly (EN) /Montageschritte (DE)

## STEP 24




D \* 2PCS



E \* 2PCS



## STEP 25



N \* 2PCS

# Assembly (EN) / Montageschritte (DE)

## STEP 26




Note: Toppling preventer must be installed otherwise there is a risk of tipping



M \* 2PCS


## STEP 27








The rollers on both sides should be fully seated in the slides as shown.


# Assembly (EN) /Montageschritte (DE)






## STEP 28



	U * 1PC
	K * 2PCS
	F * 6PCS
	D * 1PC
	E * 1PC


## STEP 29



	U * 1PC
	K * 2PCS
	F * 6PCS
	D * 1PC
	E * 1PC


# Assembly (EN) /Montageschritte (DE)

## STEP 30




	U * 1PC
	K * 2PCS
	F * 6PCS
	D * 1PC
	E * 1PC



## STEP 31




	F * 12PCS
--	-----------


STEP 32



	I * 10PCS
	F * 10PCS

STEP 33



	O * 26PCS
---	-----------