



# Product Installation Instructions







①x1




②x2




③x1




④x1




⑤x1



⑥x2




⑦x1



⑧x1



⑨x1




⑩x1




⑪x1



⑫x1



⑭x1



⑮x1




⑯x1




⑰x1




⑱x1




⑲x1




⑳x1




㉑x1



㉒x1




㉓x1



㉔x1



㉕x1




㉖x1



㉗x1




㉘x1



㉙x1



㉚x1




㉛x1




㉜x1




㉝x1



㉞x1



㉟x1




㊱x1



㊲x2




㊳x1
























㊴x1




㊵x1

















1

<b>A</b>		Two in one screw (6x28mm)	83pcs +6pcs	<b>H</b>		Cabinet door hinge & screw (3.5x12mm)	8pcs +2pcs <b>4pcs</b>
<b>B</b>		Two in one nut (10x12mm)	83pcs +6pcs	<b>I</b>		Power socket & screw (3.5x12mm)black	2pcs +1pcs <b>1pcs</b>
<b>C</b>		Wood chipping (6x30mm)	24pcs +4pcs	<b>J</b>		Non-slip pads	11pcs +3pcs
<b>D</b>		Handle & screw (4x16mm)	8pcs +2pcs <b>4pcs</b>	<b>K</b>		Fixing clip & screw (3x16mm)	12pcs +2pcs
<b>E</b>		Guide & screw (3.5x12mm)	20pcs +4pcs <b>4pcs</b>	<b>L</b>		Hook & screw (3.5x12mm)	4pcs +1pcs <b>2pcs</b>
<b>F</b>		Magnetic attraction & screw (3.5x12mm)	2pcs +1pcs <b>1pcs</b>	<b>M</b>		Laminate support nail	4pcs +1pcs
<b>G</b>		Iron sheet & screw (3x10mm)	2pcs +1pcs <b>1pcs</b>				
<b>Anti Fall Hardware</b>							
<b>O</b>	 x2  x2  x2  x4  (4x45mm)						
				 1pcs	 Double-head screwdriver, use as required		
							

# Product structure decomposition




<b>A</b>		29pcs
<b>B</b>		29pcs
<b>C</b>		8pcs
<b>D</b>	 	6pcs 3pcs
<b>E</b>	 	14pcs 4pcs
<b>J</b>		4pcs
<b>K</b>	 	4pcs




# Use parts ① and ②




Step1



Step2





Step3





Use a screwdriver to lock in the direction of the "+" sign

Disassemble along the direction of "-" sign


## Step 1





## Step 2



### Step 3





### Step 4



③ x1




## Step 5





## Step 6

### Drawer rail breakdown diagram




Step 1 : Pull the rails apart

Step 2 : Push the nylon buckle outward ①




2

3





1



2



3

## Step 7





## Step 8


A




## Step 9




## Step 10




## Step 11



⑦ x1






## Step 12











### Step 13



## Step 14



## Step 15




## Step 16

E






x1







This hole is for strengthening fixed hole customers can choose to install according to their needs.

# Step 17



## Step 18




## Step 19

Ⓔ



x1




This hole is for strengthening fixed hole customers can choose to install according to their needs.

## Step 20




B



x2




pay attention to






## Step 21




**J**






**x4**

Tear off release paper and stick the black foot pad on the board





## Step 22






## Step 23

A





## Step 24

**B**  x4





## Step 25

A





## Step 26


**B**  x5



## Step 27




## Step 28




As shown, When installing the drawer,  
pull the guide rail out first, Slide beads are also pulled out.



## Step 29











## Step 30





If a large gap is found after installing the drawer the slide rail can be moved up and down to adjust the gap

## Step 31





<b>A</b>		30pcs
<b>B</b>		20pcs
<b>C</b>		4pcs
<b>E</b>	 	6pcs 2pcs
<b>J</b>		5pcs






## Step 32

A



## Step 33




## Step 34

E




x1



This hole is for strengthening fixed hole customers can choose to install according to their needs.

## Step 35


**B**  x2






## Step 36

**B**  x2





## Step 37

Pay attention to the position of the hole






## Step 38

A



## Step 39




## Step 40

E




x1




This hole is for strengthening fixed hole customers can choose to install according to their needs.

## Step 41


**B**  x6



## Step 42



J



x5

Tear off release paper and stick the black foot pad on the board





x5

J


## Step 43


A






## Step 44

**C**  x4




## Step 45


**B**  x8























## Step 46





A




<b>A</b>		18pcs
<b>B</b>		22pcs
<b>C</b>		6pcs
<b>D</b>		2pcs
<b>F</b>		1pcs
<b>F</b>		2pcs
<b>F</b>		1pcs
<b>G</b>		2pcs
<b>G</b>		1pcs
<b>H</b>		4pcs
<b>H</b>		2pcs
<b>I</b>		2pcs
<b>I</b>		1pcs
<b>K</b>		8pcs
<b>K</b>		
<b>M</b>		4pcs






## Step 47



21




## Step 48






## Step 49

**B**  x2



## Step 50

A






## Step 51



B



x2






pay attention to



## Step 52

A




## Step 53


B



x2




## Step 54





## Step 55


C  x4




## Step 56



②⑥x1







②⑦x1





## Step 57

A





## Step 58







the back




## Step 59

Install the wooden strip first




## Step 60




I



1pcs




2pcs




I

## Step 61




## Step 62




As shown, When installing the drawer,  
pull the guide rail out first, Slide beads are also pulled out.

## Step 63




## Step 64




If a large gap is found after installing the drawer the slide rail can be moved up and down to adjust the gap

## Step 65




## Step 66







(29)x1



## Step 67




<b>H</b>		
	x1	x1
<b>G</b>		
	x1	x2




### Step 68




x1




## Step 69





## Step 70




Tighten the screw into the fixing hole

















## Step 71





Ⓓ  x1  x2



## Step 72





<b>A</b>		6pcs
<b>B</b>		12pcs
<b>C</b>		6pcs
<b>H</b>		4pcs 2pcs
<b>J</b>		2pcs
<b>L</b>		4pcs 2pcs
<b>O</b>	 x2  x2  x2  x2  x4	



## Step 73

A






## Step 74

B



x2




## Step 75

B





x1





## Step 76

A



## Step 77





## Step 78

B




x6






## Step 79

### Step 1




Insert board number 37 onto board number 36

### Step 2




## Step 80

### Step 3



### Step 4




38 x1




40 x1

## Step 81




H



x2

J



x2

Tear off the foot pad sticker and stick it on the board




x2

J





## Step 82





Step 1

Step 2





(35)x1

## Step 83




## Step 84


Hooks can be installed according to customer needs







Step 85



# Step 86



Install as required





## User's Guide

Thank you for purchasing this product.

To use this product, please plug it into a 12V DC power supply.

Please use if the product works normally after connecting to power.

## Introduction

The box is an intelligent controller. It has 1 USB output port 1 Type-c port and can distribute the current output up to 5V DC-2A. With 2 touch buttons, it can turn ON/OFF the light, change light colors, and adjust the light luminance.

## Operation




This touch button is used to turn on/off, change colors, and adjust brightness.

- A. Short touch -> lighting on -> short touch -> change light color -> short touch -> change light color -> short touch -> lighting off.
- B. Long touch -> adjust the luminance.



This touch button is used to turn on/off the induction function.

- A. Short touch to turn on the induction function. It can auto-turn on the light when people are close to the controller in 1 meters. It can auto power off the light when the body is far away from the controller after 30 seconds.
- B. Long touch to turn off the induction function.
- C. Note: When you touch the light button to change the light modes, the induction function will automatically turn off. It is best to turn on this function after selecting the light color and adjusting the brightness you want.



### ATTENTION PLEASE

1. If there is no touch response suddenly, Re-plug the power to reset the touch static electricity.
2. If bubbles appear on the panel, remove the protective film.
3. If you have any questions when installing, please feel free to contact us. Thank you.