


5.4'x3.7' TOOL STORAGE SHED

ASSEMBLY MANUAL



MODEL#::LGCF1602

Missing part? Damaged? Contact us via email at

service@domioutdoorliving.com

www.domioutdoorliving.com



PLAN AHEAD

Before beginning installation, check local building codes regarding footings, location and other requirements.

Study and understand this instruction.

Important information and helpful tips will make your installation easier and more enjoyable.

Tools and Materials: There are some basic tools and materials you will need for the installation. Decide which method of anchoring and the type of foundation you wish to use in order to form a complete list of the materials you will need.

BEFORE YOU BEGIN

Assembly Instruction: Instructions are supplied in this manual and contain all appropriate information for your installation. Review all instructions before you begin, and during assembly, follow the step sequence carefully for correct results.


Parts List: Check to be sure that you have all the necessary parts and quantities in your package. These are packaged within the carton. Note that extra fasteners have been supplied for your convenience.

Explosion Diagram: All parts except screws and bolts are shown in this diagram, review all parts before you begin. Familiarize yourself with the hardware and fasteners for easier use during installation.

SAFETY PRECAUTIONS...

*Safety precautions **MUST** be followed at all times throughout the construction of your building!*

sharp edges




Care must be taken when handling various pieces of your building since many contain sharp edges. Please wear work gloves, eye protection and long sleeves when assembling or performing any maintenance on your building.

no children or pets at worksite




Keep children and pets away from the worksite during construction and until the building is completely assembled. This will help avoid distractions and any accidents which may occur.

don't focus weight on roof



NEVER concentrate your weight on the roof of the building. When using a step ladder make sure that it is fully open and on even ground before climbing on it.

always practice proper tool safety



Practice caution with the tools being used in the assembly of this building. Be especially familiar with the operation of all power tools.

beware of wind



Do NOT attempt to assemble your building on a windy day. The large panels can catch the wind like a "sail", causing them to be whipped around making construction difficult and unsafe.

Do NOT attempt to assemble your building before double checking that you have all the parts indicated in the parts lists as well as all hardware. Any building left partially assembled may be seriously damaged by even light winds.

Pre-assembly



1. Two or more people are required for assembly.



2. You will need one or more stepladders.



3. Wearing protective gloves is recommended.



4. You may need a safety hat.



5. Please use a Phillips screw driver.



6. For ease of construction, you may need a drill.



7. You may need a safety goggle.



8. Do not fully tighten screws prior to complete assembly.

Warning & Attention

-Try to assemble this product on the flat ground, otherwise it is difficult to carry out;



-It would be much easier to assemble the product with three or more people;





























-After assembly, please check whether all screws are tightened, to prevent parts from falling apart.

▲ Use bolts to secure the frame to the ground to against the strong wind.
























Please stand inside the shed frame when installing the panels for convenience.



 <p>1582</p> <p>A1(x1)</p>			 <p>928,5</p> <p>D1(x1)</p>		
 <p>1582</p> <p>A2(x1)</p>			 <p>928,5</p> <p>D2(x1)</p>		
 <p>957</p> <p>A3(x2)</p>			 <p>1590</p> <p>E(x1)</p>		
 <p>A(x4)</p>			 <p>1104</p> <p>G1(x1)</p>		
 <p>1537</p> <p>B1(x1)</p>			 <p>1104</p> <p>G2(x1)</p>		
 <p>1537</p> <p>B2(x1)</p>			 <p>829</p> <p>G3(x2)</p>		
 <p>912</p> <p>B3(x2)</p>			 <p>829</p> <p>G4(x2)</p>		
 <p>B4(x1)</p>	 <p>B8(x1)</p>	 <p>B(x4)</p>	 <p>G5(x2)</p>	 <p>G6(x2)</p>	 <p>G7(x2)</p>
 <p>1608,5</p> <p>C(x4)</p>			 <p>1524</p> <p>H(x1)</p>		
 <p>1609</p> <p>C1(x1)</p>			 <p>899</p> <p>H1(x2)</p>		
 <p>1609</p> <p>C2(x1)</p>			 <p>Y(x4)</p>		
 <p>C3(x2)</p>		 <p>C4(x2)</p>			





List 1

<div>  <div>1608</div> <div>J (x6)</div> </div> <div>  <div>1608</div> <div>J2 (x6)</div> </div>	<div>  <div>454</div> <div>M4 (x1)</div> </div> <div>  <div>454</div> <div>M5 (x1)</div> </div> <div>  <div>454</div> <div>M6 (x1)</div> </div> <div>  <div>454</div> <div>M7 (x2)</div> </div> <div>  <div>454</div> <div>M8 (x1)</div> </div>
<div>  <div>1104</div> <div>K3 (x1)</div> </div> <div>  <div>1104</div> <div>K2 (x3)</div> </div> <div>  <div>1104</div> <div>K1 (x1)</div> </div>	<div>  <div>M9 (x1)</div> <div>  <div>M10 (x1)</div> </div> </div> <div> <div> <div>Hexagonal socket wrench</div>  </div> <div> <div>Hole position correction drill</div>  </div> </div>
<div>  <div>1582</div> <div>M (x2)</div> </div> <div>  <div>1582</div> <div>M1 (x2)</div> </div> <div>  <div>1582</div> <div>M2 (x1)</div> </div> <div>  <div>1582</div> <div>M3 (x1)</div> </div>	<div> <div>Cross screwdriver</div>  </div> <div> <div>Hand Gloves</div> <div>   </div> </div>

List 2








Hole position correction drill








If the screw holes are
not symmetrical,
you can use this tool
to correct the hole position.

PART 1


BOTTOM FRAME, WALL
PANEL AND TOP FRAME
ASSEMBLY:

	4x10	1# (x86)
	M4x6	2# (x4)
	M4x8	3# (x8)
	4x12	9# (x21)
	4x16	12# (x18)








NOTICE






M6-8pcs











TOP BEAM ASSEMBLY:

Use 16 self-tapping bolts #12 and gaskets to secure 4 Bracket #B to the top Beam #B1/B2/B3*2;
Use 2 self-tapping bolts #12 and gaskets to secure parts #B4 & B8 to the inside of part #B1.






TOP BEAM & BASE FRAME BRACKET ASSEMBLY:





J2 (x4)





C1 (x1)

C2 (x1)

C (x2)

1# (x10)

2# (x4)




Use 2 bolts 2#, gaskets and nuts to connect part #C/J2/C1 to form a front side wall panel.

Place the assembled front side wall panel (#C/J2/C1) on the bottom frame(A1), using 3 self-tapping bolts 1# and gaskets to fix.


Place wall panel #J2 on the bottom frame(A3), using 2 self-tapping bolts 1# and gaskets to fix.

Repeat the above procedures to assemble another front side wall(part #C2/J2/C/J2) .










★ You can temporarily reinforce this position(★) with screws 2#, and replace it with other correct screws when the next installation is made.

- ③ Fix part #C3 to part #C1 with 2 bolts 3#, FOUR gaskets and 2 nuts.
- ④ Fix part #C3 to part #C2 with 2 bolts 3#, FOUR gaskets and 2 nuts.




Inside View







Front Side



Back Side




Back Side Wall Assembly:

- Place part #J2 & C on the bottom frame A3, using 2 self-tapping bolts 1# and gaskets to fix.
- ①: Use 1 self-tapping bolt 9# and gasket to install support tube H1 to the front wall panel #C & J2, then put on the plastic cap.
- ③: Use 1 self-tapping bolts 9# and gasket to install support tube H1 to back wall panel #J2 & C, then put on the plastic cap.
- Repeat the above procedures to assemble another side.

Back Wall Assembly:

- ③: Use 1 self-tapping bolts 9# and gasket to install support tube #H to back wall panel #C & J, then put on the plastic cap.
Place part #J on the bottom frame #A2, using 3 self-tapping bolts 1# and gaskets to fix.
- ④: Use 1 self-tapping bolts 9# and gasket to install support tube #H to back wall panel #J & C, then put on the plastic cap.
Place part #J on the bottom frame #A2, using 3 self-tapping bolts 1# and gaskets to fix.




J (x2)

1# (x8)

9# (x4)


SIDE WALL ASSEMBLY:



Step 1: Use 4 self-tapping bolts 1# and gaskets to fix 2 part #J on the bottom frame A3.

Step 2: Use 2 self-tapping bolts 9# and gaskets to fix 2 part #J with support tube #H1, then put on the plastic caps to form a whole left side wall.

Repeat the above procedures to assemble the right side wall.




Section View



J (x2)


1# (x7)

9# (x3)





Step 3: Use 7 self-tapping bolts 1# and gaskets to fix 2 part #J on the bottom frame A2.


Step 4: Use 3 self-tapping bolts 9# and gaskets to fix 2 part #J with support tube #H, then put on the plastic caps to form a whole back wall.



Section View




①/②: Place the assembled top frame (B1/B2/B3*2) on the upper end of the wall panel, and fix with 35 self-tapping bolts 1# and gaskets.







Inside View


③/④: Fix the upper end of the part #C1/C2 with part #C4 (already assembled on top frame #B1) by using bolts 3#, the nuts and gaskets are on the back side.




PART 2


TOP BEAM AND ROOF ASSEMBLY

	4x10	1# (x29)
	M4x6	2# (x56)
	M4x8	3# (x8)
	M4x8	15# (x4)







TOP BEAM ASSEMBLY:






- ①: Use 2 bolts #15 and nuts to connect part #D1 & E.
- ②: Use 2 bolts #15 and nuts to connect part #D2 & E.



Section View


Place the assembled top beam on the top frame, and fix with 17 self-tapping bolts #1 and gaskets.






Assemble part #G1 to the one side of part #K1 with 3 bolts 2#, gaskets and nuts.

Assemble part #G2 to the one side of part #K3 with 3 bolts 2#, gaskets and nuts.




1# x12


2# x12




①: Use 12 self-tapping bolts #1 and plastic gaskets to secure the roof panel to the back top Frame #B2.




②: Use 12 bolts #2, steel gaskets and nuts to secure the roof panel to the front top beam #E.









③: Use 3 bolts #2, steel gaskets and nuts to secure the roof panel #K1 to the side top beam #D1.



Use 3 bolts #2, steel gaskets and nuts to secure the roof panel #K3 to the side top beam #D2.








Use 24 bolts #2, gaskets and nuts to install part #G3&G4 on both edge of the roof;

④: Install Gap Cover #G7 at the joint of part G3&G4, and fix with 4 bolts #2, gaskets and nuts.




3# x8

G5 x2



G6 x2






PART 3


	M4x6	2# (x16)
	M4x8	8# (x8)
	M4x8	10# (x24)

DOOR ASSEMBLY:









the front side of left door



the back side of left door




Section View





M (x1)







M9 (x1)

M10 (x1)


2# (x8)






10# (x12)




The back side of right door



The front side of right door





DOOR ASSEMBLY:




The user needs to install this section.

Our factory has pre-installed the hinge on the door frame C1/C2.







Insert the bolt and lock the left door.



Open the door: insert the key, rotate 180 counterclockwise, and rotate the handle counterclockwise to open the door.

Lock the door: close the door, insert the key, rotate the handle clockwise, then rotate the key 180 clockwise and pull the key out.



Thanks for your purchase.

At domi outdoor living, we believe in our products.

That's why we provide a 12-month warranty and friendly, easy-to-reach after-sales service. So, if you have any questions about our product or assembly, please feel free to contact us. We are here for you.

Support:



After-sales contact email:

service@domioutdoorliving.com

Please have your order ID available if you reach out for support.

If you have damaged parts or product, please send us photos for an immediate response.