

NOTICE

*Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.

*This item should be assembled on a soft surface to prevent scratching the finish during assembly.

*This item may require periodic tightening.

*If you are having difficulty, our friendly Customer Care team is always here to help.

PREPARATION

*Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.

*If any part is missing or damaged, do not attempt to assemble the product.


*Estimated Assembly Time: 60 minutes.

*Tools Required for Assembly: Phillips Head Screwdriver (Not Included) & Allen Key (Included)

CARE AND MAINTENANCE


Adhesive felt pads should always be applied to areas of furniture which make direct contact with flooring, said application will prevent damage to the furniture and or surfaces on which the furniture lies. Objects placed on articles of furniture should rest on non abrasive material as to prevent damage to the wood finish. Objects whose composition consists of plastic and rubber are known to discolor and damage the wood surfaces on which they rest. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.

Part List



Owner Manual

Product Dimensions: 46.85"Wx15.35"Dx18.78"H























⚠ WARNING

This product is intended for use with a
FLAT SCREEN TV ONLY
Maximum Screen Size: 50 inches
Weight Limit: 66 lbs
Shelf Load Limit: 33 lbs
Drawer Load Limit: - lbs
Use with heavier televisions may result
in instability causing tip over resulting in
death or Serious injury.

⚠ WARNING

Death or serious injury may occur
when children climb on audio
and/or video equipment furniture.
A remote control or toys placed on
the furnishing may encourage a
child to climb on the furnishing and
as a result the furnishing may tip
over on the child.

Hardware List

<p>HW1x5</p>  <p>∅ 6 x 35 mm</p>	<p>HW2x5</p>  <p>∅ 15 mm</p>	<p>HW3x5</p> 	<p>HW4x12</p>  <p>∅ 8 x 30 mm</p>	<p>HW5x5</p>  <p>M 7 x 50 mm</p>	<p>HW6x2</p>  <p>L 4</p>
<p>HW7x2</p> 	<p>HW8x1</p> 	<p>HW9x2</p>  <p>M 4 x 22 mm</p>	<p>HW10x2</p> 	<p>HW11x2</p> 	<p>HW12x8</p>  <p>M 3.5 x 13 mm</p>
<p>HW13x4</p> 	<p>HW14x12</p>  <p>M 6.4 x 45 mm</p>	<p>HW15x12</p>  <p>M 3.5 x 15.5 mm</p>	<p>HW16x4</p> 	<p>HW17x2</p> 	<p>HW18x2</p> 
<p>HW19x4</p> 	<p>HW20x12</p> 				

Part List & HW For Multi-Box Items

Piece	Description	Qty
A	Top Board	1
B	Bottom Board	1
C	Side Board Left	1
D	Side Board Right	1
E	Center Board	1
F	Door	1
G	Back Board	2

Piece	Description	Qty
HW1	Cambolt	5
HW2	CamLock	5
HW3	Screw Cap	5
HW4	Dowel	12
HW5	Screw M 7 x 50 mm	5
HW6	Allen Key	2
HW7	Silicon Bumper	2
HW8	Handle	1
HW9	Screw M 4 x 22 mm	2
HW10	Sliding Top	2
HW11	Sliding Bottom	2
HW12	Screw M 3.5 x 13 mm	8
HW13	Support Corner Brace&Screw M 6 x 40 mm	4
HW14	Screw M 6.4 x 45 mm	12
HW15	Screw M 3.5 x 15.5 mm	12
HW16	Corner Brace	4
HW17	Support Metal Leg 1	2
HW18	Support Metal Leg 2	2
HW19	Metal Square Leg	4
HW20	Wedge	12

PREPARATION


*Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.

*If any part is missing or damaged, do not attempt to assemble the product.


*Estimated Assembly Time: 60 minutes.

*Tools Required for Assembly: Phillips Head Screwdriver (Not Included) & Allen Key (Included)


*If you are having difficulty, our friendly Customer Care team is always here to help.




STEP1: Insert Cambolt (HW1) into Top Board (A). Insert Dowel (HW4) into Side Board Left (C), Side Board Right (D) and Center Board (E).



STEP2: Attach Side Board Left (C), Side Board Right (D) and Center Board (E) into Top Board (A). Insert Camlock (HW2) then tighten using screwdriver. Put Screw Cap (HW3) over the camlock.




Step3: Insert Back Boards (G) as figure. Put Bottom Board (B) and secure with Screw M7x50 mm (HW5), tighten screws using Allen Key (HW6).




STEP4: First, remove the M6 x 40 mm screw (HW13B) from the Support Corner Brace (HW13A). Second, insert the Support Corner Brace (HW13A) into the Leg (HW19), ensuring that the hole in the Support Corner Brace aligns with the hole in the Leg. Third, insert the M6 x 40 mm screw (HW13B) into the hole in the Corner Brace (HW16), and insert it into the hole in the Leg, then tighten it slightly.

PREPARATION


- *Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- *If any part is missing or damaged, do not attempt to assemble the product.
- *Estimated Assembly Time: 60 minutes.
- *Tools Required for Assembly: Phillips Head Screwdriver (Not Included) & Allen Key (Included)
- *If you are having difficulty, our friendly Customer Care team is always here to help.




STEP5: Place Support Metal Leg 1 (HW17) and Support Metal Leg 2 (HW18) on the floor as shown in the image. Then, install the prepared leg (HW19). Ensure that the Corner Brace (HW16) hooks into the holes of Support Metal Leg 1 (HW17) and Support Metal Leg 2 (HW18). Use the Allen Key (HW6) to slightly tighten the screws, just enough to hold the Support Metal Legs in place. Do not fully tighten them. Repeat this process for the remaining legs.



STEP7: Insert Sliding Top (HW10) and Sliding Bottom (HW11) using Screw M3.5x13mm (HW12) into Door (F). Tighten with a screwdriver. Use Screw M4x22mm (HW9) to attach Handle (HW8) to the Door.




STEP6: Install assembled leg unit from Step 5 onto main assembled unit by inserting Screw (HW14). Tighten with Allen Key (HW6). Then tighten all the Screw on the 4 corner brace of the assembled leg unit.




Step8: Peel the back paper of Bumper (HW7) then 2 pcs on Door position as shown in the figure. Insert the Sliding Top (HW10) pin into the groove line of Top Board. Position the Sliding Bottom (HW11) into the grooved sliding track. Adjust gap of the door, by scroll the button on Sliding Roller (HW11). Follow the down and up direction. Slide the door to right and left ensuring the door has been placed properly in the provided track.

PREPARATION


- *Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- *If any part is missing or damaged, do not attempt to assemble the product.
- *Estimated Assembly Time: 60 minutes.
- *Tools Required for Assembly: Phillips Head Screwdriver (Not Included) & Allen Key (Included)
- *If you are having difficulty, our friendly Customer Care team is always here to help.



STEP9: Use Wedge (HW20), Screw M 3.5 x15.5mm (HW15) to tighten the back of media stand by using screwdriver. Please align the top board and bottom board in 90° position against the side board, before securing the wedges (HW20).



STEP10: Place your furniture on level floor. The legs come with adjustable leveller, adjust it as needed until your furniture sit steady on the floor.



STEP11: Assembly is complete.

TIPPING RESTRAINTS KIT INSTALLATION GUIDANCE

Different wall materials require unique wall fasteners.

The wall plugs (AA2) and screws (AA3) are designed for fixing to concrete walls only.

Please consult your local hardware store to ensure you are using the correct hardware for your wall type.

