

**installation instructions:**

# ACOUSTIXPRO SLAT WALL PANELS

## SAFETY INSTRUCTIONS

Make sure to use the correct tools recommended.

Wear proper protective gear.

Follow fixture, power tools, and paint manufacturers' instructions and users manuals.

Use common sense and follow good construction practices.

## TOOL & MATERIAL CHECKLIST

- Box knife
- Black screws
- Drill or screwdriver
- Measuring tape
- Chalk line
- Circular or Table Saw
- Fine sandpaper
- Quality Paint or stain
- Paint brush or roller


## IMPORTANT INFO

- Before installing, acclimate the wood Slats in the room where you will be installing them.
- Clean and prep the installation surface and each Slat of any debris with a clean cloth.
- It is highly recommended that you paint or stain the panels before installation.
- It is recommended to use quality and stain for all wood species.
- Make sure the surface of the panel is completely dry before installation.
- In most applications you will have to trim some panels. Cut them with a standard table saw or power tool if you need to cut where there is wood. Sand cut edge ends and clean away any debris. To cut the backing, use a standard box knife.

## INSTALL INSTRUCTIONS:

1. Prep and stain Slats before installing. Touch up stain as needed after installation.
2. Smooth installation surface with sandpaper by removing excessive bumps or texture. Wipe wall clean to clear debris.
3. We recommend laying out the desired layout before installation as these are completely customizable and space is up to you. Mark the installation points using a chalk line or straight edge and level.
4. Secure with black screws between the slats, going through black backing. (We recommend at least 7 on each end of the panel.)
5. Once the first one is installed, repeat step 4 on the rest of the AcoustixPro panels.
6. Once you reach the end and need to cut down the panel, use a box knife to cut through the backing to desired size.  
\*To trim down the length of the panel, we recommend using a circular or table saw.

## EXAMPLE DIAGRAM:



Industry leading manufacturer of urethane, PVC, wood, rustic, and metal millwork

We Can Help. Call (866) 607-0453

[www.ekenamillwork.com](http://www.ekenamillwork.com)