

J1S019




As this item contains many parts, please read the installation instruction carefully before installation . Please use tools properly and carefully. If you have any questions about the product and installation, please contact us.

hosoteservice@gmail.com

Our professional after-sales team will serve you online all day.

Before You Start



- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware of to slow down and stop when screw is tight. Failure to do so may result in stripping the screw. (Assembly speed can be increased by using electric screwdriver)

Helpful Hints

PEOPLE NEEDED FOR ASSEMBLY: 1-2

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.



- Identify, sort and count the parts before attempting assembly.

- Compression dowels are lightly tapped in with a hammer.



- Slides are labeled with an **R** (right) and **L** (left) for proper placement.



- Make sure to always face the point on the top of the Cam Lock towards the outer edge.

- If there is a back panel in the package, please install it to make sure your unit is complete and sturdy.



- Please fix all the screws provided for the back panel which can enhance product stability. If it is difficult to fix it when tightening, it can be fixed with the help of a hammer and then tightened.




- Do NOT use harsh chemicals or abrasive cleaners on this item.



- Never push, pull, or drag your furniture.


Board Identification

Not actual size




TOP PANEL

Qty:1




BOTTOM PANEL

Qty:1




LEFT SIDE PANEL

Qty:1




MIDDLE DIVIDER PANEL

Qty:1




RIGHT SIDE PANEL

Qty:1




LEFT DOOR

Qty:1




RIGHT DOOR

Qty:1




BACK PANEL

Qty:1




LEFT FRONT BAR

Qty:1




RIGHT FRONT BAR

Qty: 1



FRONT UPPER BAR

Qty: 1




FRONT BOTTOM BAR


Qty: 1

Board Identification


Not actual size




BACK BOTTOM BAR
Qty:1




FIXED PANEL
Qty:1




SHELF PANEL
Qty: 3



BACK PANEL
Qty:1




BACK PANEL
Qty:1




BACK PANEL
Qty: 2


Part List




CAM BOLT
spare: 3




CAM LOCK
spare: 3




WOOD DOWEL
spare: 3




HINGE




SCREW
spare: 3




HANDLE




BOLT
spare: 1




METAL PLATE
spare: 1




HOOK




SCREW
spare: 2




MAGNET




SCREW
spare: 1




HANGING ROD SUPPORTS




PLASTIC FEET
spare: 1




BOLT
spare: 1




PANEL SUPPORTER
spare: 2




PLASTIC BUCKLE
spare: 2



L SHAPED PLATE




HANGING ROD




WALL ANCHOR
spare: 1

Part List



SCREW


spare: 1



ALLEN KEY


Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.






Board Identification

Not actual size



STEP1



D	X3

Ø4X14mm	
E	X9




F	X1

M4X19mm	
G	X2











H	X2

Ø3X14mm	
J	X4





STEP2









Flip to other side













STEP3



STEP4











STEP5




STEP 6

Attention: Please be careful not to install the magnet in the opposite direction



A X4



J X2



K X4

Ø3X14mm








L X8





M X1


STEP 7





STEP 8





	
Ø6.5X35mm	
A	X5



	
Ø15X10 mm	
B	X6

	
Ø8X30mm	
C	X5








	
N	X2



STEP 9







STEP 10




Proper orientation of CAM LOCK

STEP 11







1. Insert the back panel (17) into the frame assembled in the previous step.
2. Connect panel (3) (9) to the frame by using wood dowel (C) and cam lock (B).




Proper orientation of CAM LOCK

STEP 12








Proper orientation of CAM LOCK

STEP 13







Insert back panel(18)

STEP 14




Proper orientation of CAM LOCK

STEP 15





Proper orientation of CAM LOCK


STEP16





STEP 17






 Ø15X10 mm	
B	X8

 Ø8X30mm	
C	X8






Proper orientation of CAM LOCK


STEP18





STEP19




STEP 20






 Ø3X14mm	
J	X 16

	
Q	X 16



STEP 21



STEP 22

